


# Modular Indirect Fired Heaters and Inserts Installation, Operation, and Maintenance Manual



Modular Indirect Fired Heater



Indirect Fired Module



Indirect Fired Furnace

## **FOR YOUR SAFETY**

If you smell gas:

1. Open windows.
2. Don't touch electrical switches.
3. Extinguish any open flames.
4. Immediately call your gas supplier.

## **FOR YOUR SAFETY**

The use and storage of gasoline or other flammable vapors and liquids in open containers in the vicinity of this appliance is hazardous.

## **RECEIVING AND INSPECTION**

Upon receiving unit, check for any interior and exterior damage. If damage is found, report it immediately to the carrier. Also check that all accessory items are accounted for and are damage free. Turn the blower wheel by hand to verify free rotation and check the damper (if supplied) for free operation.

## **WARNING!!**

Improper installation, adjustment, service or maintenance can cause property damage, injury or death. Read the installation, operating and maintenance instructions thoroughly before installing or servicing this equipment. ALWAYS disconnect power and gas prior to working on heater.

**Save these instructions.** This document is the property of the owner of this equipment and is required for future maintenance. Leave this document with the owner when installation or service is complete.



## TABLE OF CONTENTS

WARRANTY .....	4
Furnace Warranty .....	4
CERTIFICATIONS AND PATENTS .....	4
Listing .....	4
Patents .....	4
INSTALLATION .....	4
Mechanical .....	5
Site Preparation .....	5
Assembly .....	5
Curb and Ductwork .....	6
Roof Mount Installation .....	7
Installation with Exhaust Fan .....	7
Indirect Fired Module Installation .....	8
Indoor (INLINE) Installation .....	8
Condensation Drain .....	9
Indoor Flue Venting .....	10
Gas .....	13
LP Conversion Kit .....	14
Electrical .....	16
Input AC Power .....	17
Fan to Building Wiring Connection .....	17
COMPONENTS .....	18
Part Identification .....	18
Motor Speed Control Options .....	21
Variable Frequency Drive Speed Control (Installation Instructions) .....	22
ACTECH SMV VFD .....	23
Optional Components .....	24
OPERATION .....	24
HMI Configuration .....	24
HMI Options Screen .....	25
HMI Menu Description .....	25
HMI Menu Tree .....	30
Start Up .....	38
Tools Required .....	38
Start Up Procedure .....	38
Gas Pressure Adjustment .....	39
Furnace Start-Up (Summary) .....	40
Furnace Startup .....	41
Final Start-Up Procedure .....	43
Pulley Adjustment .....	43
Pulley Alignment/Proper Belt Tension .....	44
Pulley Combination Chart .....	45
High Altitude Orifice Sizing .....	46
Sequence of Operation (Summary) .....	47
Sequence of Operation (Detailed) .....	47
Re-Circulating Control Options .....	50
Manual Positioning Control .....	50
Two Position Control .....	50
Outdoor Air % .....	50
Static Pressure Control (Photohelic) .....	51
A306 Outdoor Sensor .....	52
Building Signal Damper Control .....	52
Schedule Control .....	52
Network .....	53
BACNET .....	53
LonWorks .....	56
SERVICE INFORMATION .....	57
Troubleshooting Flow-charts .....	57
Fault Codes .....	58
Airflow Troubleshooting Chart .....	60
Furnace Troubleshooting Chart .....	61
VFD Fault List .....	62
Component Testing .....	63
MAINTENANCE .....	67
General Maintenance .....	68
2 weeks after startup .....	69
Every 3 months .....	69
Yearly .....	70
Heat Exchanger Inspection .....	71
Appendix A – IBT Board Electrical Connections .....	72
Appendix B – IBT DDC Points .....	76
IBT DDC Fault Codes .....	80
Start-Up and Maintenance Documentation .....	84
Job Information .....	84
Heater Information .....	84
Maintenance Record .....	84

## **WARRANTY**

This equipment is warranted to be free from defects in materials and workmanship, under normal use and service, for a period of 2-years from date of shipment. This warranty shall not apply if:

1. The equipment is not installed by a qualified installer per the MANUFACTURER'S installation instructions shipped with the product.
2. The equipment is not installed in accordance with Federal, State, and Local codes and regulations.
3. The equipment is misused or neglected, or not maintained per the MANUFACTURER'S maintenance instructions.
4. The equipment is not operated within its published capacity.
5. The invoice is not paid within the terms of the sales agreement.

The MANUFACTURER shall not be liable for incidental and consequential losses and damages potentially attributable to malfunctioning equipment. Should any part of the equipment prove to be defective in material or workmanship within the 2-year warranty period, upon examination by the MANUFACTURER, such part will be repaired or replaced by MANUFACTURER at no charge. The BUYER shall pay all labor costs incurred in connection with such repair or replacement. Equipment shall not be returned without MANUFACTURER'S prior authorization and all returned equipment shall be shipped by the BUYER, freight prepaid to a destination determined by the MANUFACTURER.

### **Furnace Warranty**

Subject to all terms stated herein, the MANUFACTURER warrants to BUYER the stainless-steel heat exchanger to be free from defects in material and workmanship under normal use and service for 25-years from the date of manufacture, and warranty is limited to replacement of the heat exchanger only.

## **CERTIFICATIONS AND PATENTS**

### **Listing**

This unit is ETL-listed to standard American National Standard/CSA Standard for Gas Unit Heaters And Gas-Fired Duct Furnaces ANSI Z83.8-2016, CSA 2.6-2016.

### **Patents**

The Indirect Bent Tube Heater is covered under the following patent: Heated Make-Up Air: United States Patent No. 8777119 B2.

## **INSTALLATION**

It is imperative that this unit is installed and operated with the designed airflow, gas, and electrical supply in accordance with this manual. If there are any questions about any items, please call the service department at **1-866-784-6900** for warranty and technical support issues.

## Mechanical

**WARNING: DO NOT RAISE VENTILATOR BY THE INTAKE HOOD, BLOWER OR MOTOR SHAFT, OR BEARINGS – USE ALL LIFTING LUGS PROVIDED WITH A SPREADER BAR OR SLINGS UNDER THE UNIT**


### **CLEARANCES**

The top, back, and front surfaces of this heater may not be installed less than 6" from combustible materials. The heater base may be installed on combustible surfaces. Allow 24" minimum service clearance on both sides of this heater.

## Site Preparation

1. Provide clearance around installation site to safely rig and lift equipment into its final position. Supports must adequately support equipment. Refer to manufacturer's estimated weights.
2. Consider general service and installation space when locating unit.
3. Locate unit close to the space it will serve to reduce long, twisted duct runs.
4. Do not allow air intake to face prevailing winds. Support unit above ground or at roof level high enough to prevent precipitation from being drawn into its inlet. The inlet must also be located at least 10 feet away from any exhaust vents. The heater inlet shall be located in accordance with the applicable building code provisions for ventilation air.

**Figure 1 – Spreader Bar**



### **IMPORTANT**


To prevent premature heat exchanger failure, do not locate any gas fired unit in areas where chlorinated, halogenated, or acid vapors are present in the atmosphere.

## Assembly

Intakes and curbs are shipped unassembled to heater module. Upon unit arrival, use the following procedure to assemble the intake to the heater.

1. Apply silicone or weather-proof gasket on the back side of the flanges of the intake hood or v-bank intake.
2. Screw the flanges of the intake hood or v-bank to the unit with the supplied sheet metal screws. Place caulk on the outside of the screws to prevent water leaks. If the unit is a modular unit with a v-bank or evaporative cooler section, the v-bank or evaporative cooler will bolt to the heater with the bolts provided.

**Figure 2- Intake and Curb Assembly**



## Curb and Ductwork

This fan was specified for a specific CFM and static pressure. The ductwork attached to this unit will significantly affect the airflow performance. When using rectangular ductwork, elbows must be radius throat, radius back with turning vanes. Flexible ductwork and square throat/square back elbows should not be used. Any transitions and/or turns in the ductwork near the fan outlet will cause system effect. System effect will drastically increase the static pressure and reduce airflow.

- **Table 1** shows the minimum fan outlet duct sizes and straight lengths recommended for optimal fan performance.
- **Follow SMACNA standards and manufacturer's requirements for the duct runs.** Fans designed for rooftop installation should be installed on a prefabricated or factory built roof curb. Follow curb manufacturer's instructions for proper curb installation.
- **Do not use unit to support ductwork in any way. This may cause damage to the unit.**
- The unit should be installed on a curb and/or rail that meets local code height requirements.
- Make sure duct connection and fan outlet are properly aligned and sealed.
- Secure fan to curb through vertical portion of the ventilator base assembly flange using a minimum of eight (8) lug screws, anchor bolts, or other suitable fasteners (not furnished). Shims may be required depending upon curb installation and roofing material.
- Check all fasteners for tightness. **Figure 3** through **Figure 6** show different mechanical installation configurations.

**Table 1 - Recommended Supply Ductwork**


Blower Size (Inches)	Discharge	Duct Size (Inches)	Straight Duct Length (Inches)
10	Side	14 x 14	48
	Down/Up		
15D, 16Z, 18Z	Side	20 x 20	72
	Down/Up	14 x 14	48
12	Side	16 x 16	54
	Down/Up		
15	Side	20 x 20	72
	Down/Up		
20D, 20Z, 22Z	Side	26 x 26	108
	Down/Up	20 x 20	72
18	Side	24 x 24	86
	Down/Up		
24D, 25Z	Side	30 x 30	108
	Down/Up	24 x 24	86
20	Side	26 x 26	108
	Down/Up		
30D, 28Z	Side	32 x 32	168
	Down/Up	26 x 26	108
25	Side	32 x 32	168
	Down/Up		
36D	Side	36 x 36	189
	Down/Up	32 x 32	168

### **WARNING!!**

**Failure to properly size ductwork may cause system effects and reduce the performance of the equipment.**


# Roof Mount Installation

## Figure 3




# Installation with Exhaust Fan

## Figure 4




# Indirect Fired Module Installation

Figure 5



# Indoor (INLINE) Installation

Figure 6



## Condensation Drain

In some applications, condensation can form in the flue collection box, primarily when furnaces are located downstream of cooling coils. If condensation occurs in the flue collection boxes, there are barbed fittings in the bottom of the flue collection boxes to drain condensation out of the boxes. Each burner in the unit is provided with a burner drain pan or a condensation drain assembly located underneath this fitting for the condensation to collect. If the drain assembly is installed on the heater, it will have 1/4" quick seals located below the front access door for field piping or drainage onto the roof. Consult your local code as to the proper drainage regulations of the condensation. The internal drain piping is heated to prevent freezing. If drains are field piped, ensure that the field piping is installed to avoid the condensation from freezing. Do not plug the holes under any circumstance, as it will cause the burners to overflow.

In the event the IBT does not have condensation drains and condensation exceeds the pan capacity, IBT condensation drain kits can be ordered for installation in the field.

The part names for the kits are:


- "IBT Condensation Kit-1" Single Furnace IBT
- "IBT Condensation Kit-2" Double Furnace IBT
- "IBT Condensation Kit-3" Triple Furnace IBT
- "IBT Condensation Kit-4" Quadruple Furnace IBT

## Condensate Drain Trap Installation


When a drain trap is required, refer to **Figure 9** for trap details. If you do not install the trap as described, drainage system failures will occur.

1. The trap depth must be  $1/2 \times$  the trap height. For example, if the trap height is 6", the trap depth must be 3".
2. All joints must be water tight.
3. After the exit from the trap, the drain must be pitched down from the unit connection at least 1" for every 10 feet of horizontal run to promote proper drainage. Check local installation code, if allowed, the drain can be routed to a wastewater system.
4. When the trap can experience freezing temperatures, drain the system or use a heating device. This will prevent water from freezing and damaging the trap.
5. The trap must be primed before the unit is put into operation and properly maintained on a regular schedule.
6. To prime the trap, remove the cleanout cap. Fill the trap with water. Put the cleanout cap back onto the drainage system. Make sure the trap is operating properly.


**Figure 7 – 1/4" NPT Condensation Drain**



**Figure 8 – IBT Condensation Drain Assembly Connections**



**Figure 9 – Trap Dimensions**



## Indoor Flue Venting

This appliance requires a Category III venting system. Refer to appliance manufacturer's installation instructions for proper vent installation. Indoor gas fired heating equipment must be vented. **Do not operate un-vented.** Gas fired heating equipment which has been improperly vented, or which experiences a blocked vent condition may emit flue gases into heated spaces.

**IMPORTANT**  
Furnace Only Modules must be installed in a positive pressure airstream. Do not install in a duct on the suction side of a fan.

**Use only venting materials and components that are UL listed and approved for Category III venting systems. Do not mix pipe, fittings, or joining methods from different manufacturers.**

### General Venting Guidelines

1. Installation of venting must conform to local building codes, or in the absence of local codes, follow the National Fuel Gas Code.
2. **On Units with multiple furnaces, each furnace must be ducted to the outside using its own isolated duct run. Ducts used on each single furnace MUST NOT be connected together in any fashion. Failure to adhere to this may result in a build-up of Carbon-Monoxide in the space when the furnace is operating with less than all of its furnaces powered.**
3. Do not use a vent pipe smaller than the size of the outlet on the heater.
4. Install with a minimum upward slope from unit of ¼ inch per foot and suspend from overhead structure at points no greater than 3 feet apart. For best venting, put as much vertical vent as close to the unit as possible.
5. Fasten individual lengths of vent together with at least three corrosion resistant sheet metal screws.
6. Vent pipes should be fitted with a tee with a drip leg and clean out tap at the low point in the vent run. This should be inspected and cleaned out periodically during the heating season.
7. Do NOT use dampers or other devices in the vent or combustion air pipes.
8. Use a vent terminal to reduce downdrafts and moisture in the vent line.
9. A vent system that terminates vertically but has a horizontal run that exceeds 75% of the vertical rise is considered horizontal.
10. Pressures in Category III venting systems are positive, and therefore care must be taken to prevent flue products from entering the heated space.
11. Vent pipes must all be sealed and gastight.


### Vertically Vented Furnaces

1. Use single wall or double wall (Type B) vent pipe of a diameter listed in the following table for the appropriate model.
2. Maximize the height of the vertical run of vent pipe. A minimum of five (5) feet (1.5m) of vertical pipe is required. The top of the vent pipe must extend at least two (2) feet (0.61m) above the highest point on the roof. Use Listed Type B vent for external runs. An approved weatherproof vent cap must be installed on the vent termination.
3. Horizontal runs should be pitched upward ¼ in. per foot (21mm/m) and should be supported at three (3) foot (1m) maximum intervals.
4. Design vent pipe runs to minimize the use of elbows. Each 90° elbow is equivalent to five (5) feet (1.5m) of straight vent pipe.
5. Vent pipe should not be run through unheated spaces. If such runs cannot be avoided, insulate the vent pipe to prevent condensation. Insulation should be a minimum of ½ in. (12.7mm) thick foil faced fiberglass minimum of 1½ # density.
6. Dampers must not be used in vent piping runs, as spillage of flue gases into the occupied space could result.
7. Vent connectors serving Category 1 heaters must not be connected into any portion of a mechanical draft system operating under positive pressure.

#### **National Fuel Gas Code Venting Pipe requirement**

75,000-149,999	Use 5-inch pipe
150,000-400,000	Use 6-inch pipe

**Figure 10 - Vertical Venting**



### Horizontally Vented Furnaces – Category III

Horizontal vent systems terminate horizontally (sideways)

**WARNING: Do not use Type B vent within a building on horizontally vented units.**

1. All vent pipe joints must be sealed to prevent leakage. Follow the instructions provided with the approved venting materials.
2. The total equivalent length of vent pipe must not exceed 50 ft. (15.25m). Equivalent length is the total length of straight sections, plus 5 ft. (1.52m) for each 90° elbow and 2.5 ft. (0.76m) for each 45° elbow.
3. The vent system must also be installed to prevent collection of condensates. Horizontal runs should be pitched upward ¼ in. per foot (21mm/m) and should be supported at three (3) foot (1m) maximum intervals.
4. Insulate vent pipe exposed to cold air or routed through unheated areas. Insulate vent pipe runs longer than 10 ft. (3m). Insulation should be a minimum of ½ in. (12mm) thick foil faced fiberglass of 1 ½ # density. Maintain 6 in. (152mm) clearance between vent pipe and combustible materials.
5. An approved Breidert Type L, Field Starkap or equivalent vent cap must be provided. Vent cap inlet diameter must be the same as the vent pipe diameter.
6. The vent terminal must be at least 12 in. (305mm) from the exterior wall that it passes through to prevent degradation of building material by flue gases.
7. The vent terminal must be located at least 12 in. (305mm) above grade, or in snow areas, at least 3 ft. (1m) above snow line to prevent blockage.
8. The vent terminal must be installed with a minimum horizontal clearance of 4 ft. (1.2m) from electric meters, gas meters, regulators, or relief equipment.

Through-the-wall vents shall not terminate over public walkways or over an area where condensate or vapor could create a nuisance or hazard. Provide vent termination clearances to building or structure features as follows:

**Structure Minimum**

Door, Window or gravity inlet

Forced air inlet within 10 ft. (3m)

Adjoining building or parapet

Adjacent public walkways

**Clearance**

4 ft. (1.2 m) below

4 ft. (1.2 m) horizontally


1 ft. (305 mm) above

3 ft. (.91 m) above

6 ft. (1.8 m)

7 ft. (2.1 m) above grade

**Figure 11 - Horizontal Venting**



**EACH APPLIANCE MUST HAVE ITS OWN INDIVIDUAL VENT PIPE AND TERMINAL. Do not connect vent system from horizontally vented units to other vent systems or a chimney**

## Gas

Installation of gas piping must conform with local building codes, or in the absence of local codes, to the National Fuel Gas Code, ANSI Z223.1 (NFPA 54) – latest edition. In Canada, installation must be in accordance with CAN/CGA-B149.1 for natural gas units and CAN/CGA-B149.2 for propane units.

### **WARNING: INLET GAS PRESSURE MUST NOT EXCEED 14 IN. W.C. SEE UNIT RATING PLATE FOR PROPER GAS SUPPLY PRESSURE AND GAS TYPE.**

1. Always **disconnect power** before working on or near a heater. Lock and tag the disconnect switch or breaker to prevent accidental power up.
2. Piping to the unit should conform to local and national requirements for type and volume of gas handled, and pressure drop allowed in the line. Refer to the Gas Engineer's Handbook for gas line capacities.
3. The incoming pipe near the heater should be sized to match the connection on the outside of the unit. Unit inlet sizes are shown in **Table 2**. Avoid multiple taps in the gas supply so the unit always has a steady supply of gas .
4. Install a ground joint union with brass seat and a manual shut-off valve external to the unit casing, as shown in **Figure 12**, adjacent to the unit for emergency shut-off and easy servicing of controls.
5. Provide a sediment trap, as shown below, before each unit and where low spots in the pipe line cannot be avoided.
6. Blow out the gas line to remove debris before making connections. Purge line to remove air before attempting to start unit. Purging of air from gas lines should be performed as described in ANSI Z223.1-latest edition "National Fuel Gas Code", or in Canada in CAN/CGA-B149.
7. All field gas piping must be pressure/leak tested prior to unit operation. Use a non-corrosive bubble forming solution or equivalent for leak testing. The heater and its individual shut-off valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of ½ psi. The heater must be isolated from the gas supply piping system by closing its individual manual shutoff valve during any pressure testing of the gas supply piping system at test pressures equal to or less than ½ psi.
8. This unit requires a constant **7 in. w.c. minimum natural gas supply, (LP should be 11 in. w.c. minimum)** when the unit is operating at maximum gas flow. If the gas supply exceeds **14 in. w.c.** it will damage the internal valve components, and if it is below 7 in. w.c., the heater may not perform to specifications.


**Table 2 – Gas Sizing Reference**

Cabinet Size	# of Furnaces	Module 1 Gas Pipe Size (NPT)	Module 2 Gas Pipe Size (NPT)
1	1	¾"	N/A
1	2	¾"	N/A
2	1	1"	N/A
2	2	1"	N/A
3	1	1"	N/A
3	2	1"	N/A
3	3	1"	1"
4	2	1"	N/A
4	3	1"	1"
4	4	1"	1"
5	2	1"	N/A
5	3	1"	1"
5	4	1"	1"

**Table 3 - Gas Pressure**

Gas Pressure Type	Gas Pressure
Inlet Pressure - Natural Gas	7 in. w.c. – 14 in. w.c.
Inlet Pressure - Propane	11 in. w.c. – 14 in. w.c.
Max. Manifold Pressure - Natural Gas	3.5 in. w.c. maximum
Max. Manifold Pressure - Propane	10 in. w.c. maximum
Min. Manifold Pressure - Natural Gas	0.15 in. w.c. minimum
Min. Manifold Pressure - Propane	0.75 in. w.c. minimum

**Figure 12 – Gas Connection Diagram**



### **NOTICE**

**Refer to the heater rating plate for determining the minimum gas supply pressure for obtaining the maximum gas capacity for which this heater is specified.**

## LP Conversion Kit

LP/Natural gas conversion kits are used to convert from one gas type to another in the field. This kit is used on all units and the part numbers below should be used on furnace sizes listed. Kits contain:

- Main Safety Gas Valve Regulator Spring
- Furnace orifices clearly indicated with orifice size

This unit is configured for the gas type listed on the nameplate. To convert gases, you must replace the following parts listed in the table below. The size specific parts include the orifice conversion parts and the combination gas valve spring(s). These parts are available by contacting the phone number in this manual. All field gas piping must be pressure/leak tested prior to unit operation. Use a non-corrosive bubble forming solution or equivalent for leak testing. The equipment and its individual shut-off valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of 1/2 psi. The equipment must be isolated from the gas supply piping system by closing its individual manual shutoff valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 psi. This must be performed on an annual basis.

**Table 4 - Gas Conversion Kit Part Numbers**

Gas Type	Modulating Valve Part Number	Furnace Size (MBH)				
		150	200	250	300	400
Natural	E50	NAT-HMG150	NAT-HMG200	NAT-HMG250	NAT-HMG300	NAT-HMG400
LP	E50	LP-HMG150	LP-HMG200	LP-HMG250	LP-HMG300	LP-HMG400

### Pre-Conversion Unit Check-Out

The following procedure is intended as a guide to aid in determining that the appliance is properly installed and is in a safe condition for continuing use. It should be recognized that generalized test procedures cannot anticipate all situations. Accordingly, in some cases, deviation from this procedure may be necessary to determine safe operation of the equipment:

- This procedure should be performed prior to any attempt at modification of the appliance or the installation.
- If it is determined there is a condition that could result in unsafe operation, the appliance should be shut off and the owner advised of the unsafe condition.

The following steps should be followed in making the safety inspection:

1. Conduct a gas leakage test of the appliance piping and control system downstream of the shut-off valve in the supply line to the appliance.
2. Visually inspect the venting system for proper size and horizontal pitch and determine there is no blockage or restrictions, leakage or corrosion, or other deficiencies which could cause an unsafe condition.
3. Shut off all gas to the appliance and shut off any other fuel-burning appliance within the same room. Use the shut-off valve in the supply line to each appliance.
4. Inspect burners and crossovers for blockage and corrosion.
5. Inspect heat exchangers for cracks, openings, or excessive corrosion.
6. Insofar as is practical, close all windows and all doors between the space in which the appliance is located and other spaces of the building. Turn on any exhaust fans, so they will operate at maximum speed. After completing steps 6 through 10, it is believed sufficient combustion air is not available, refer to the section covering air for combustion, venting and ventilation of *Natural Gas and Propane Installation Code, CSA B149.1, or National Fuel Gas Code, ANSI Z223.1/NFPA 54*, for guidance.
7. Place the appliance in operation following the lighting instructions. Adjust thermostat so the appliance will operate continuously. Other fuel-burning appliances shall be placed in operation.

8. Determine that the pilot is burning properly and that the main burner ignition is satisfactory by interrupting and re-establishing the electrical supply to the appliance in any convenient manner;
  - a. Visually determine that main burner gas is burning properly, i.e. no floating, lifting, or flashback. Adjust the primary air shutter(s) as required.
  - b. If the appliance is equipped with high- and low-flame control, or flame modulation, check for proper main burner operation at low flame.
9. Test for spillage at the draft hood relief opening after 5 minutes of main burner operation. Use a draft gauge, the flame of a match, or candle.
10. Return doors, windows, exhaust fans, and all other fuel-burning appliances to their previous conditions of use.
11. Check both limit control and fan control for proper operation. Limit control operation can be checked by temporarily disconnecting the electrical supply to the blower motor and determining that the limit control acts to shut off the main burner gas.

## Electrical

### **WARNING!!**

**Disconnect power before installing or servicing fan. High voltage electrical input is needed for this equipment. This work should be performed by a qualified electrician.**

Before connecting power to the heater, read and understand this entire section of this document. As-built wiring diagrams are furnished with each fan by the factory and are attached to the door of the unit.


Electrical wiring and connections should be made in accordance with local ordinances and the National Electric Code, ANSI/NFPA70. Be sure the voltage and phase of the power supply and the wire amperage capacity are in accordance with the motor nameplate. For additional safety information, refer to AMCA publication 410-96, *Recommended Safety Practices for Users and Installers of Industrial and Commercial Fans*.

1. Always **disconnect power** before working on or near a heater. Lock and tag the disconnect switch or breaker to prevent accidental power up.
2. An electrical drop containing the motor power wiring is shipped with every fan. The electrical drop should be brought through one of the conduit openings located in the base of the unit, run through the curb, and connect to a junction box inside the building.
3. A dedicated branch circuit should supply the motor circuit with short circuit protection according to the National Electric Code. This dedicated branch should be run to the junction box and connected as shown in **Figure 14**.
4. Make certain that the power source is compatible with the requirements of your equipment. The heater nameplate identifies the **proper phase and voltage** of the motor.
5. Units shipped with an optional remote HMI panel have separate wiring requirements. It is important to route the main electrical wires (high voltage) in a separate conduit from the remote HMI Cat 5 wiring (low voltage). Maximum distance on any low voltage wire is 1000 feet.
6. Before connecting the heater to the building's power source, verify that the power line wiring is de-energized.
7. Secure the power cables to prevent contact with sharp objects.
8. Do not kink power cable and never allow the cable to come in contact with oil, grease, hot surfaces or chemicals.
9. Before powering up the heater, check fan wheel for free rotation and make sure that the interior of the heater is free of loose debris or shipping materials.
10. If any of the original wire supplied with the heater must be replaced, it must be replaced with type TW wire or equivalent.

**Table 5 - Copper Wire Ampacity**

Wire Size AWG	Maximum Amps
14	15
12	20
10	30
8	50
6	65
4	85

**Figure 13 – Electrical Drops**




## Input AC Power

1. Circuit breakers feeding the VFDs are recommended to be thermal-magnetic and fast acting. They should be sized based on the VFD amperage and according to **Table 6**. Refer to the installation schematic for exact breaker sizing.
2. Each VFD should be fed by its own breaker. If multiple VFDs are to be combined on the same breaker, each drive should have its own protection measure (fuses or miniature circuit breaker) downstream from the breaker.
3. Input AC line wires should be run in conduit from the breaker panel to the drives. AC input power to multiple VFDs can be run in a single conduit if needed. **Do not combine input and output power cables in the same conduit.**
4. The VFD should be grounded on the terminal marked PE. A separate insulated ground wire must be provided to each VFD from the electrical panel. This will reduce the noise being radiated in other equipment.
5. Motors should be grounded to the VFD ground terminal only. Do not connect the motor ground to the heater ground terminal.

## Fan to Building Wiring Connection

Figure 14




# COMPONENTS

## Part Identification

The following image and list identify typical indirect fired heater components and their functions.


Figure 15 – Typical Main Cabinet



#	Name	Description
1.	<b>Exhaust Flue Pipe</b>	Ventilates combustion between the power-vent exhaust discharge and top of the unit.
2.	<b>Flame Roll-Out Switch</b>	Normally closed temperature activated switch. Mounted on bracket at inlet of the upper-most firing tube. Senses flame roll-out in the event of a blocked tube, low airflow, or low gas pressure. If flame-rollout is present, the switch de-energizes heater circuit on individual furnace. Must be manually reset by pressing small red button on back.
3.	<b>Flame Sensor</b>	Continuously senses for the presence of flame in heating mode after ignition has commenced. Wired to Flame Safety Control.
4.	<b>Contactor</b>	Contactor with overload protection to start and protect motor.
5.	<b>750VA Transformer</b>	The transformer is designed to change one voltage to another by magnetic induction.
6.	<b>Control Transformer</b>	120V primary; 24V secondary control transformer.
7.	<b>Control Transformer</b>	120V primary; 24V secondary control transformer.
8.	<b>Terminal Strip</b>	Central location to terminate control wiring. Should be used for troubleshooting.
9.	<b>Circuit Breaker</b>	Protects electrical components from high current spikes.
10.	<b>Dirty Filter Airflow Switch (Optional)</b>	Senses whether the filters at the intake to the main blower are free of dirt and contaminant.
11.	<b>Main Airflow Switch</b>	Senses that there is main airflow across the Heat-exchanger of the furnace. Adjustable set-point. Heater circuit will not energize unless proven.

#	Name	Description
12.	<b>Power-vent Airflow Switch</b>	Normally open, non-adjustable airflow switch. Senses whether the power-vent blower is running and allows furnace to spark when airflow is proven.
13.	<b>Flame Safety Control</b>	Initiates and monitors flame. Equipped with non-adjustable time settings for pre-purge, inter-purge, and post-purge of the exhaust flue and control cabinet.
14.	<b>IBT Board</b> <b>*2 required if heat stages &gt; 2</b>	Controls the 0-10V DC signal to the modulating gas valve(s), speed controller(s) and 24V AC signals to staged furnace controls. Speed controllers are built into the board. Main board DIP switches should all be set to off. When a slave board is used, the slave board DIP switch 1 should be set to on. Slave board DIP switches 2, 3 and 4 should remain off. Use a Cat-5 cable from J5 of main board to J1 or J2 of slave board.
15.	<b>Cabinet Heater (Optional)</b>	Recommended for winter design temperatures of 0°F or below.
16.	<b>Modulating Valve Control Transformer</b>	120V primary; 24V secondary control transformer. Provides standing 24V power to Modulating Gas Valve.
17.	<b>HMI</b>	IBT Board interface. The 4 buttons are used to navigate through the menus. (There can be up to 4 additional HMIs added. These can be used for interface or as a part of space tempering)

Figure 16 – Typical Burner Cabinet



#	Name	Description	
1.	<b>Power-vent Motor</b>	Induces airflow through heat exchanger and flue of furnaces A) Modulating furnace variable speed blower motor. B) Non-modulating furnace constant speed blower motor.	
		<b>Power Vent Motor Orifice Size</b>	
		<b>Furnace BTU (x1000/hr)</b>	<b>Dia. (in.)</b>
		400	2.625
		300	2.25
2.	<b>Main Disconnect Switch</b>	Controls all electrical power to entire unit.	
		<b>3. Fan Motor Speed Control Options:</b>	
		<b>PSC Motor Speed Control (Not Shown)</b>	Manual knob split capacitor fan motor speed control.
3.	<b>ECM Speed Control (Not Shown)</b>	Electronic motor speed control	
	<b>Variable Frequency Drive (Shown)</b>	Used in place of motor starter to protect main blower motor and to control the speed of the main blower to vary main airflow across unit.	
4.	<b>High pressure gas switch</b>	Monitors pressure and cuts off the electrical control circuit when pressure rises above the desired set point. (Optional)	
5.	<b>Manifold Gas Pressure Gauge</b>	Indicates manifold gas pressure on individual furnace.	
6.	<b>Flame Roll-Out Switch</b>	Normally closed temperature activated switch. Mounted on bracket at inlet of the upper-most firing tube. Senses flame roll-out in the event of a blocked tube, low airflow, or low gas pressure. If flame-rollout is present, the switch de-energizes heater circuit on individual furnace. Must be manually reset by pressing small red button on back.	

#	Name	Description
7.	<b>On/Off Gas Valve</b>	On/off gas valve with built in regulator and manual shut off switch. One used on each furnace gas train.
8.	<b>Modulating Gas Valve</b>	Controls the amount of gas to the furnace to meet desired discharge/Space temperature. <b>(Modulating units only)</b>
9.	<b>Low pressure gas switch</b>	Monitors pressure and cuts off the electrical control circuit when pressure drops below the desired set point. (Optional)
10.	<b>Main Inlet Gas Pressure Gauge</b>	Indicates inlet gas pressure to unit.
<b>Not Shown:</b>		
-	<b>High Limit Switch</b>	Normally closed high temperature switch. De-energizes heater circuit on individual furnace if temperature exceeds mechanical set-point. Automatic recycling, 200°F set-point.
-	<b>Spark Ignitor</b>	Powered by Flame safety control to initiate light-off.
-	<b>Discharge Sensor</b>	10k Thermistor. Controls the discharge to which the heating module heats to and constantly tries to maintain. Freezestat and discharge Firestat functionality is built into this sensor if the options are enabled.
-	<b>Intake Air Sensor (not shown)</b>	10k Thermistor. Reports intake temperature to the IBT board. Heating/cooling will activate based off the set points on the IBT Board. Does not control the temperature to which the unit heats the discharge. Located in the supply fan,

## Motor Speed Control Options

### ECM (Electronically Controlled Motor) Speed Control

EC motors and control allows accurate manual adjustment of fan speed. The benefit of EC motors is exceptional efficiency, performance, and motor life.

When using an EC motor, the blower control should be set to ECM. This menu item is located under factory settings > unit options > blower configuration. Once this is set, there is a PWM rate setting under user settings. This will be used to control the speed of the EC motor. The PWM signal will be sent directly to the ECM via J13-(2) PWM + and J13-(9) PWM (-) pins.

**NOTE: A Variable Frequency Drive (VFD) is required to adjust the speed control of a non-electrically commutated 3 phase direct drive motor.**

### External PWM Signal

The fan unit will be shipped with power wiring and communication wiring fed to an internal junction box. The fan is shipped with Shielded Twisted Pair (STP) wire which is used to wire to a remote PWM signal. Red wire is used to go to the positive PWM signal and black wire is used to go to the negative PWM signal. Reference schematics for all wiring connections. STP is connected to the communication wiring of the motor using wire nuts in the junction box. If a preset length of STP is provided, it will be connected to the junction box from the factory. Run the STP through any available knockout in the fan base.

## Variable Frequency Drive Speed Control (Installation Instructions)

**ATTENTION! DO NOT CONNECT INCOMING AC POWER TO OUTPUT TERMINALS U, V, W. SEVERE DAMAGE TO THE DRIVE WILL RESULT. INPUT POWER MUST ALWAYS BE WIRED TO THE INPUT L TERMINAL CONNECTIONS (L1, L2, L3)**

### VFD Output Power

1. Motor wires from each VFD to its respective motor **MUST** be run in a **separate steel** conduit away from control wiring and incoming AC power wiring to avoid noise and crosstalk between drives. An insulated ground must be run from each VFD to its respective motor. Do not run different fan output power cables in the same conduit.
2. VFD mounted in ECP: If the distance between VFD and the motor is greater than the distances specified below, a load reactor should be used between VFD and motor. The load reactor should be sized accordingly and installed within 10 feet of the output of the VFD.  
**208/230V** – Load reactor should be used when distance exceeds 250 feet.  
**460/480V** – Load reactor should be used when distance exceeds 50 feet.  
**575/600V** – Load reactor should be used when distance exceeds 25 feet.
3. VFD mounted in fan: The load reactor should be sized accordingly when VFD is mounted in the fan.  
**208/230V** – Load reactor is optional but recommended for 15 HP and above motors.  
**460/480V** – Load reactor is optional but recommended for 7.5 HP and above motors.  
**575V/600V** – Load reactors are required for all HP motors.
4. If the distance between VFD and the motor is extremely long, up to 1000 FT, a dV/dT filter should be used. The VFD should be increased by 1 HP or to the next size VFD. The dV/dT filter should be sized accordingly and installed within 10 feet of the output of the VFD.  
**208/230V** – dV/dT filter should be used when distance exceeds 400 feet.  
**460/480V** – dV/dT filter should be used when distance exceeds 250 feet.  
**575/600V** – dV/dT filter should be used when distance exceeds 150 feet.
5. No contactor should be installed between the drive and the motor. Operating such a device while the drive is running can potentially cause damage to the power components of the drive.
6. When a disconnect switch is installed between the drive and motor, the disconnect switch should only be operated when the drive is in a STOP state.

### VFD Programming

1. The Drive should be programmed for the proper motor voltage. P107 is set to 0 (Low) if motor voltage is 120V AC, 208V AC or 400V AC. P107 is set to 1 (High) if motor voltage is 230V AC, 480V AC or 575V AC.
2. The Drive should be programmed for the proper motor overload value. P108 is calculated as Motor FLA x 100 / Drive Output Rating (available in table below).

### To enter the PROGRAM mode to access the parameters:

1. Press the Mode (M) button. This will activate the password prompt (PASS).
2. Use the Up and Down buttons to scroll to the password value (the factory default password is “0225”) and press the Mode (M) button. Once the correct password is entered, the display will read “P100”, which indicates that the PROGRAM mode has been accessed at the beginning of the parameter menu.
3. Use the Up and Down buttons to scroll to the desired parameter number.
4. Once the desired parameter is found, press the Mode (M) button to display the present parameter setting. The parameter value will begin blinking, indicating that the present parameter setting is being displayed. The value of the parameter can be changed by using the Up and Down buttons.
5. Pressing the Mode (M) button will store the new setting and also exit the PROGRAM mode. To change another parameter, press the Mode (M) button again to re-enter the PROGRAM mode. If the Mode button is pressed within 1 minute of exiting the PROGRAM mode, the password is not required to access the parameters. After one minute, the password must be re-entered in order to access the parameters again.

P500 parameter provides a history of the last 8 faults on the drive. It can be accessed without getting into PROGRAM mode.

# ACTECH SMV VFD

## Table 6 – Cross-Reference Table

HP	Part Number	Volts	1Ø Input	3Ø Input	Input Amps 1Ø 120V AC	Input Amps 1Ø 240V AC	Output Amps	Breaker 1Ø 120V AC	Breaker 1Ø 240V AC
0.33	ESV251N01SXB571	120/240V	X	-	6.8	3.4	1.7	15	15
0.5	ESV371N01SXB571	120/240V	X	-	9.2	4.6	2.4	15	15
1	ESV751N01SXB571	120/240V	X	-	16.6	8.3	4.2	25	15
1.5	ESV112N01SXB571	120/240V	X	-	20	10	6	30	20

HP	Part Number	Volts	1Ø Input	3Ø Input	Input Amps 1Ø	Input Amps 3Ø	Output Amps	Breaker 1Ø	Breaker 3Ø
0.5	ESV371N02YXB571	240V	X	X	5.1	2.9	2.4	15	15
1	ESV751N02YXB571	240V	X	X	8.8	5	4.2	15	15
1.5	ESV112N02YXB571	240V	X	X	12	6.9	6	20	15
2	ESV152N02YXB571	240V	X	X	13.3	8.1	7	25	15
3	ESV222N02YXB571	240V	X	X	17.1	10.8	9.6	30	20
5	ESV402N02TXB571	240V	-	X	-	18.6	16.5	-	30
7.5	ESV552N02TXB571	240V	-	X	-	26	23	-	40
10	ESV752N02TXB571	240V	-	X	-	33	29	-	50
15	ESV113N02TXB571	240V	-	X	-	48	42	-	80
20	ESV153N02TXB571	240V	-	X	-	59	54	-	90
<b>480V</b>									
1	ESV751N04TXB571	480V	-	X	-	2.5	2.1	-	15
1.5	ESV112N04TXB571	480V	-	X	-	3.6	3	-	15
2	ESV152N04TXB571	480V	-	X	-	4.1	3.5	-	15
3	ESV222N04TXB571	480V	-	X	-	5.4	4.8	-	15
5	ESV402N04TXB571	480V	-	X	-	9.3	8.2	-	15
7.5	ESV552N04TXB571	480V	-	X	-	12.4	11	-	20
10	ESV752N04TXB571	480V	-	X	-	15.8	14	-	25
15	ESV113N04TXB571	480V	-	X	-	24	21	-	40
20	ESV153N04TXB571	480V	-	X	-	31	27	-	50
25	ESV183N04TXB571	480V	-	X	-	38	34	-	70
30	ESV223N04TXB571	480V	-	X	-	45	40	-	80
<b>600V</b>									
1	ESV751N06TXB571	600V	-	X	-	2	1.7	-	15
2	ESV152N06TXB571	600V	-	X	-	3.2	2.7	-	15
3	ESV222N06TXB571	600V	-	X	-	4.4	3.9	-	15
5	ESV402N06TXB571	600V	-	X	-	6.8	6.1	-	15
7.5	ESV552N06TXB571	600V	-	X	-	10.2	9	-	20
10	ESV752N06TXB571	600V	-	X	-	12.4	11	-	20
15	ESV113N06TXB571	600V	-	X	-	19.7	17	-	30
20	ESV153N06TXB571	600V	-	X	-	25	22	-	40
25	ESV183N06TXB571	600V	-	X	-	31	27	-	50
30	ESV223N06TXB571	600V	-	X	-	36	32	-	60

## Optional Components

### Electric Cabinet Heater

Units can be shipped with an optional 120V electric cabinet heater powered from the IBT board. There is a temperature sensor built onto the IBT Board that will regulate when the cabinet heater activates.

### Motorized Intake Damper

On units shipped with the optional motorized intake damper, a power transformer is supplied with the unit if the main incoming voltage is greater than 120V. The damper motor is energized whenever the blower gets a call to run. **No external wiring to the damper motor is required.**


### AC Interlock

On units equipped with an optional AC interlock, 24V AC power from Y1 in the condensing unit or rooftop unit should be field wired to screw terminal J11-(5) on the IBT board. 24V AC common from C in the condensing unit or rooftop unit should be field wired to terminal block J11-(8) on the IBT board. When these terminals are powered, heat will be locked out on the IBT.

### Remote (HMI) Control Panel

On units shipped with a space HMI, a Cat 5 cable will need to be run from J3 on the main IBT Board to J2 on the HMI. If additional space HMIs have been added, they can be daisy chained from the first HMI. In the event there is a slave IBT board, HMIs can also be powered from J1 or J2 of the slave board. An end of line resistor should be added to the last HMI in the chain.

Figure 17 – Space HMI



## OPERATION

### HMI Configuration

#### General Overview

The HMI allows the user to change parameters, and options. You can use the HMI to view operating Information regarding sensors, temperatures, pressures, and fault history.

There are four buttons to navigate through the HMI screens.

**Note: Buttons change functions during certain options, and tests. Verify the screen, and buttons throughout the menu display.**

The user can access the HMI configuration screen by pressing the top two buttons simultaneously. To exit this screen, simply press the BACK button. When setting certain options or functions, pressing the BACK button multiple times will bring up the reboot screen. The user may select 'YES' to save the changes or select 'NO' to return to factory settings, or select 'CANCEL'. When selecting 'CANCEL', any changes made will not be saved, and the screen will return to the top menu.

The HMI menu system allows full access to every configurable parameter in the HMI. The parameters are factory configured to the specific application. Parameters may need to be modified to fine tune automatic operation after the original setup.

Figure 18 – Idle Screen





Figure 19 – Warning Screen



## HMI Options Screen

To set the HMI number or to adjust the screen contrast, press the bottom two buttons simultaneously on the HMI faceplate. Use the UP and Down buttons to select the parameter that will be adjusted. Press Enter to select the highlighted parameter.

Setting the HMI number configures the Modbus address for that HMI.


To change the contrast, select “Advanced Options”. The user may adjust the setting from 0 to 10. Setting the contrast to 0 is the lowest setting available and 10 is the highest contrast setting available. The factory default contrast setting is 5.

## HMI Notification Letters

The HMI will display notification letters when the unit is in a specific status.

- When the blower is in a delay, a “B” will be displayed.
- When the condensers are in a Min ON or Min OFF time, a “T” will be displayed.

**Figure 20 – Notification Letters**



## HMI Menu Description

### USER SETTINGS

(Any changes within this menu do not require a reboot to take effect)

- **Temp Set Points** – Some of these may not be available based on settings. If scheduling is enabled there will be both occupied and unoccupied values for each set point.
- **Scheduling** – This menu will only show when scheduling option has been turned on. Each day contains the option for two occupied time periods. If the time is scrolled past 11:59pm it will display UNOCC.
- **Copy Schedule** – This will allow the user to copy an existing schedule from one day of the week to individual days in the week, to Week Days, or ALL.
- **Fan Speed** - Enabled when blower control is set to VFD Manual. The range of this menu is limited by the min and max frequency set points under factory settings. When occupied scheduling is set to on, occupied and unoccupied settings are available.
- **HMI Dimming Timer** - Configurable menu time until dim, 10 seconds - 60 seconds.
- **PWM Rate** - Enabled when blower control is set to ECM. This will be used to control the speed of the ECM motor. The PWM signal will be sent directly to the ECM motor. When occupied scheduling is set to on, occupied and unoccupied settings are available.
- **Mixing Box Voltage** - Enabled when 'Mixing Box Config' is set to 'Manual'. Voltage output to air box damper.
- **Outdoor Air %** - Enabled when 'Mixing Box Config' is set to 'Schedule', or 'Outdoor Air %'. Limited by min and max outdoor air percentages in factory settings. When occupied scheduling is set to on, occupied and unoccupied settings are available.
- **Active Faults** – Contains the current faults on the board
- **Fault History** - Will show time stamped history of the last 20 faults, most recent fault showing first.
- **Reset Fault Lockout** – Resets lock out faults.

## FACTORY SETTINGS

(Password = 1111)

(These will be set job specific from the plant. Any changes within this menu require a reboot to take effect. **Upon exiting factory settings, if anything has been altered, the board will reboot itself.** Password = 1111. There is a 5 minute timer before having to re-enter password.)

- **Temperature Control** - If scheduling is enabled there will be both occupied and unoccupied values for each set point.
  - Tempering Mode Heat – Discharge, Space, Analog Control, DDC, None.
  - Tempering Mode Cool – Intake, Space, Analog Control, DDC, None.
  - Activate Based On – Intake, Space, Both, Either, Stat. Default is Either.
- **Heating Config**
  - # Of Heat Stages – 0, 1, 2, 3, 4 heat stages.
  - Intake Heat Hysteresis (Hyst) – Intake sensor must go this amount of degrees above the set point before heating will turn off.
  - Space Heat Hysteresis (Hyst) – Space sensor must go this amount of degrees above the set point before heating will turn off.
  - Heater Firing Order – Standard, alternate. Standard firing order is furnace 1, 2, 3, 4. Alternate firing order is furnace 2, 1, 3, 4. This option has no effect for single furnace units.
  - Input Source – 0-10V DC, 2-10V DC, 0-20 mA, 4-20 mA. This lets the board know what signal to expect from an Analog Control system.
  - Cabinet Diff – This is the differential for the cabinet heater. The outdoor air temp must reach this many degrees above the activation set point to turn off.
  - Freezestat Timer – The discharge temp must stay below the freezestat set point for this amount of time before the unit will lock out on freeze stat.
  - ROT Delay – This is the time after a furnace loses a call for heat before the furnace shuts down.
  - RCT Delays – If the heat stage value is greater than 1, the user may adjust Relay Close Time (RCT) delay for stages 2, 3, 4. Range settings is 30-600 seconds.

RCT Delay Defaults (in Seconds)			
RCT	Stage 2	Stage 3	Stage 4
1	0	0	0
2	120 s	90 s	90 s
3	0	120 s	90 s
4	0	0	120 s

- **Cooling Config**
  - Cooling Type – None, DX, Evap, Both. If “None” is selected all cooling options under user settings are hidden.
  - Min Cool OA Temp – When the space temperature is calling for cooling, and the outdoor air temperature is below the set point, the unit will shut the condensers off, and start the blower to use outdoor air to cool the space. Default is 55°F. Range setting is 40-90°F.
  - Condenser Staging – 0, 1, 2, or 3 condensers. Within the 2 and 3 condenser selection, there is another submenu which allows for 2 or 3 stages. For 2 condenser units, 3 stages should only be selected when the condensers are of unequal tonnages.
  - Intake Cool Hysteresis (Hyst) – Intake sensor must fall this many degrees below the set point for the stage to turn off.
  - Space Cool Hysteresis (Hyst) – Space sensor must fall this many degrees below the set point for the stage to turn off.
  - Cond Min Time On – Minimum time each condensing stage must remain on after becoming activated. This is to prevent stage cycling. **A “T” will be present in the lower left corner of the home screen when any of the condensers are in a MIN ON/OFF TIME.**
  - Cond Min Time Off – Minimum time each condensing stage must remain off after being deactivated. This is to prevent stage cycling. **A “T” will be present in the lower left corner of the home screen when any of the condensers are in a MIN ON/OFF TIME.**
  - Evap Config (continued)
    - Spray Time On – Time the evaporative cooler will spray in the cycle.
    - Spray Time Off – Time the evaporative cooler will be idle in the cycle.
    - Evap Drain – On/Off. Default is Off.
    - Evap Drain SP – This setting will monitor outside air so that the water does not freeze within the evaporator module. Default setting is 40°F. Range setting is 35-50°F.

## FACTORY SETTINGS

(Password = 1111)

- Evap Config (continued)
  - Drain Differential – Temperature differential setting before the drain shuts off. Default setting is 2°F. Range setting is 1-5°F.
  - Evap Differential – Temperature differential before the evap cooling shuts off. Default setting is 3°F. Range setting is 1-10°F.
- Min Evap OA Temp – When the space temperature is calling for cooling, and the outdoor air temperature is below the set point, the unit will shut the evap off, and the blower will use outdoor air to cool the space. Default is 80°F. Range setting is 60-100°F.
- **Occupied Scheduling** – This menu is where the scheduling can be turned On or Off. Default is Off.
- **Occupancy Override** – This menu is where the occupancy override can be turned On or Off. Default is On.
- **Unit Options**
  - **Board Config**
    - IBT Address – Modbus address of the IBT board.
    - Startup Timer – Time upon power up where the board will sit idle.
    - Celsius/Fahrenheit – Celsius, Fahrenheit. Changing between the two will reset all set points.
    - # of HMIs – Number of HMIs connected to the IBT board. Must always be at least one.
    - HMI Averaging – If there are multiple space HMIs connected, this menu allows you to select which will be included in the space averaging. If a thermistor is connected into the ST screw terminals, it will automatically be averaged into any HMIs included.
    - HMI Dimming – This is an On/Off menu. Default is set to Off. If set to On, a 'HMI Dimming Timer' option will be available under 'User Settings'.
    - Screensaver - This is an On/Off menu. Default is set to On. If set to Off, the home screen will not time out to the screensaver.
  - **Blower Config**
    - Blower Control – 120V Contactor, VFD Manual, VFD Jog, VFD 0-10V, ECM, ECM 0-10V.
      - 120V Contactor – 120V output on the IBT board to drive the coil of a contactor. This option should be selected when the IBT is used in conjunction with a DCV package.
      - VFD Manual – HMI selectable VFD frequency.
      - VFD Jog – For use with VFD using photohelic control. Uses the aux pins to control the VFD. Powering aux 1 will speed the fan up, powering aux 2 will slow the fan down. When aux 1 or aux 2 are not powered, the VFD will hold current speed.
      - VFD 0-10V – For use when an external 0-10V signal is being provided to control the speed of the VFD. The VFD output from this input will be based on the VFD min and max freq set under protected params in factory settings. 0 Volts will equal VFD min, 10V will equal VFD max, and all voltages in between will be scaled linearly. This option will utilize 0-10V J14-(6) and 0-10V common J14-(7) screw terminals and will require field wiring.
      - Electronically Controlled Motor (ECM) - HMI selectable PWM rate.
      - ECM 0-10V - For use when an external 0-10V signal is being provided to modulate the ECM supply output between min and max speed.
    - Blower Mode – If the Occupied Scheduling is set to ON, the menu screen for the blower mode will allow you to choose ON/AUTO/OFF for Occupied or Unoccupied. If the Occupied Scheduling is set to OFF, the menu screen for the blower mode will allow you to choose MANUAL/AUTO/OFF. In blower auto mode, the blower will only run when it gets a call for heating/cooling. In blower manual mode, the blower will run as long as the fan button is enabled regardless of whether the unit is heating/cooling. In blower off mode, powering the unit interlock pin will cause the blower to run. This setting should be used when an IBT is covered by a prewire package.

## FACTORY SETTINGS

(Password = 1111)

- Blower Start Delay – On, Off. Enabling this menu will run the furnace before starting the blower. **A “B” will be present in the lower-left corner when the unit is in a blower START/STOP DELAY.**
- Blower Stop Delay – On, Off. Enabling this menu will stop the furnace and allow the blower to run until timer expires. **A “B” will be present in the lower-left corner when the unit is in a blower START/STOP DELAY.**
- Blower Delay Time – This sets the time that the furnace will run before the blower starts.
- Blower Preset Speed – This allows the user to set blower preset option On or Off.
- VFD Direction – Sends a command to the VFD to run in forward or reverse.
- Fan Speed Presets - Uses aux pins to control supply fan VFD, see **Table 7**.
- Occ Fan Presets – Occupied scheduled presets 1-7.
- Unocc Fan Presets – Unoccupied scheduled presets 1-7.
- **Purge Config**
  - Purge Button – On, Off. This function will be active when the mixing box is enabled. When the purge button is pressed, the mixing box dampers will open to max outdoor air and turn on the exhaust contactor.
  - Purge Time – This is setting is adjustable from 1 – 120 minutes, default is 15 minutes. This is the amount of time that the unit will run the purge process, if the user does not stop the purge manually.
  - VFD Purge Speed – Adjustable between VFD Min and Max frequency. This is the speed the blower will run during the purge cycle. Default is 60 Hz.
  - ECM Purge Speed – This is the speed the blower will run during the purge cycle. This is adjustable between PWM Min and Max frequency.
- **Monitoring Sensors** – These are On/Off menus. Default is Off.
  - Smoke Detector, Filter Monitor, Intake Firestat, Discharge Firestat, Freezestat, Low Gas Switch, High Gas Switch.
- **Mixing Box Config**
  - Mixing Box – None, Manual, 2 Position, Schedule, Outdoor Air %, 100% OA, Analog Control.
  - Mixing Box Deadband – If the temperature difference between the outdoor and return sensor is less than or equal to this set point, the IBT board will not attempt to adjust the output voltage until it matches the outdoor air percentage set point. This setting only takes effect when either outdoor air % or schedule is selected.
  - Return As Space – On, Off. Setting this to on will not require a space sensor or HMI. It will use the return air thermistor (RT) in place of the space sensor.
  - Min Outdoor Air % - Minimum allowed outdoor air percentage. User can set occupied and unoccupied percentage range.
  - Max Outdoor Air % - Maximum allowed outdoor air percentage. User can set occupied and unoccupied percentage range.
  - Off Position – Allows user to select how the dampers will be positioned when the supply fan is off. Standard (default), Max Outdoor Air %, or Min Outdoor Air %.
  - Damper Presets – This allows the user to set damper preset option On or Off.
  - Preset Volts – Uses aux pins to control damper actuator, see **Table 8**.

**Table 7 – Fan Speed Presets**

PRESET	AUX 1	AUX 2	AUX 3
Speed 1	X		
Speed 2		X	
Speed 3	X	X	
Speed 4			X
Speed 5	X		X
Speed 6		X	X
Speed 7	X	X	X

**Table 8 – Damper Presets**

PRESET	AUX 1	AUX 2	AUX 3
Position 1	X		
Position 2		X	
Position 3	X	X	
Position 4			X
Position 5	X		X
Position 6		X	X
Position 7	X	X	X

## FACTORY SETTINGS

(Password = 1111)

- **Intake Damper** – On, Off.
- **Room Override** – On, Off option. This setting will only have an effect when the heat tempering mode is set to Discharge and “Activate Based On” is set to “Either” (intake or space temperature). When the space is calling for heat it will use the Room Override SP instead of Discharge SP to heat the space.
- **Exhaust Cntctr (Contactor)** – Off, before airflow, after airflow. If scheduling is enabled there will be both occupied and unoccupied values for each set point.
- **Exhaust On Smoke** – Off, On. Input that when enabled, if it receives a 120V signal from a fire system, will shut down the supply fan and enable the exhaust contactor.
- **Cabinet Heater** – On, Off.
- **Drain Heater** – On, Off.
- **Occupied Override (Occpd Ovr) Duration** – Length of override timer. If override is active it can be manually stopped by pressing the end override button on the HMI. The default setting is 1 hour but can be adjusted up to 16 hours.
- **Limit Set Point (SP) Adjust** - This allows the user to change the current temperature set point from the home screen. The range adjustment is 0-100 degrees. The default is 5 degrees. When the setpoint is set to 0°F/C the adjustment buttons (+/-) will not be visible.
- **Protected Params** – VFD Min and Max Frequency can be adjusted here. **PID values within this menu should not be changed**


## SERVICE SETTINGS


(Password = 1234)


- **Temperatures** – Menu to view all of the temperature sensors.
- **Discharge Disp Offset** – Display offset for discharge temp. This can be used if actual discharge temperature is measured differently on site.
- **Space Disp Offset** – Display offset for space temp. This can be used if actual space temperature is measured differently on site.
- **Inputs**
  - Open/Closed Status – Menu to view the open/closed status of all inputs.
  - Voltages – Voltage Inputs. Analog Control, Air quality, Mixing Box Damper, Indoor RH and Outdoor RH.
  - VFD Status – Live parameter feedback from the VFD.
- **Outputs** – Board output equipment status.
- **Test Menu** – To stop any test, hit the abort button on the HMI.
  - Test Fans – All, Supply, Exhaust.
  - Test Heating – Contains high and low fire tests for stages. If “Heating Config” is set to 0, then “No Heat Stage Set” will display.
  - Test Cooling Evap/DX– All, 1, 2, 3, Evap. If “Cooling Config” is set to none, then “No Cooling Type Set” will display.
  - Test Analog Control – This test will simulate a voltage input from an analog control system. The test will begin at 0 volts. The up and down buttons allow for modulation of input.
  - Test Options.
    - Cabinet Heater – Beginning this test will turn the cabinet heater on.
    - Drain Heater – Beginning this test will turn the drain heater on.
    - Mixing Box – Beginning this test will create an output to the mixing box. The test will begin at 0 volts. The up and down buttons allow for modulation of the output.
- **Clear Fault History** – Will clear the entire fault history. If there is an active fault when cleared, that fault will show up until it is fixed.
- **Factory Reset** – Will reset board to factory commissioned settings.
- **Update Factory Defaults** – This allows the original factory default settings to be overridden. When confirming the updated settings, these settings will now be used when “Factory Reset” is needed.


# HMI Menu Tree

The top menu of the IBT Board contains 3 main categories. These categories are user settings, factory settings, and service.




















## Start Up

Prior to starting up or operating the heater, check all fasteners for tightness. In particular, check the set screw in the wheel hub, bearings, and the fan sheaves (pulleys). With power and gas to the heater OFF or prior to connecting ventilator to power, turn the fan wheel by hand to be sure it is not striking the inlet or any obstacles. Re-center, if necessary.

### Tools Required

- AC Voltage Meter
- Tachometer
- Standard hand Tools
- Amperage Meter
- Manometer
- Thermometer

### Start Up Procedure


1. Check all electrical connections for tightness and continuity.
2. Check pulley alignment and belt tension as shown in [Pulley Alignment/Proper Belt Tension](#) (page 44).
3. Inspect the condition of the intake damper and damper linkage, if provided.
4. Inspect the air-stream for obstructions and install intake filters if missing.
5. Compare the supplied **motor voltage** with the fan's nameplate motor voltage. If this does not match, correct the problem.
6. Start the fan up by turning the external disconnect to the **ON** position, and shut it **OFF** immediately. **Check rotation of the wheel** with the directional arrow on the blower scroll. Reversed rotation will result in poor air performance, motor overloading and possible burnout. For units equipped with a single-phase motor check the motor wiring diagram to change rotation. For 3-phase motors, any two power leads can be interchanged to reverse motor direction.
7. When the fan is started up, observe the operation and check for any unusual noises.

## Gas Pressure Adjustment

Table 9 - Reference Information (Natural Gas)

		# of Furnaces in Unit			
		1 Furnace	2 Furnaces	3 Furnaces	4 Furnaces
Gas Valve Regulator Settings	1st Furnace (Modulating)	On/Off Valve Fully Open Maxitrol Modulating Valve @ 3.5" w.c.	On/Off Valve Fully Open Maxitrol Modulating Valve @ 3.5" w.c.	On/Off Valve Fully Open Maxitrol Modulating Valve @ 3.5" w.c.	On/Off Valve Fully Open Maxitrol Modulating Valve @ 3.5" w.c.
	2nd Furnace (On/Off or Modulating)	N/A	On/Off Valve Fully Open Maxitrol Modulating Valve @ 3.5" w.c.	On/Off Valve Fully Open Maxitrol Modulating Valve @ 3.5" w.c.	On/Off Valve Fully Open Maxitrol Modulating Valve @ 3.5" w.c.
	3rd Furnace (On/Off)	N/A	N/A	3.5" w.c.	3.5" w.c.
	4th Furnace (On/Off)	N/A	N/A	N/A	3.5" w.c.

Figure 21 – Typical Furnace Layout



## Furnace Start-Up (Summary)

### Setting Incoming Pressure

Pressure must be measured at the first “T” in the supply gas line before the first gas valve.

### Adjusting On/Off Stages

Remove the pressure regulator adjustment cover screw on the On/Off valve and using a screwdriver. Refer to **Table 9** for proper adjustment settings based on # of furnaces in the unit. Turn the inner adjustment screw clockwise to increase the gas flow and counter-clockwise to decrease the gas flow. Replace the pressure regulator adjustment screw cover.

### Adjusting the High Fire (modulating stage)


Set pressure according to **Table 9**. Press and hold button #1 down on the modulating gas valve until the LED light is solid red. This will drive the valve into its fully open position. Adjust high fire. Press or hold button #1 to increase gas flow. Press or hold button #2 to decrease gas flow. Hold down both buttons to save the high fire setting.

### Adjusting the low fire (modulating stage)

Low fire manifold pressure:

- The desired pressure reading for natural gas is **0.15”**. If this cannot be obtained, set the low fire pressure as low as possible.
- The pressure reading for propane gas should be **0.75”**.

Press and hold button #2 down on the modulating gas valve until the LED blinks red. This will drive the valve into its minimum flow position. Adjust low fire. Press or hold button #1 to increase gas flow. Press or hold button #2 to decrease gas flow. Hold down both buttons to save the low fire settings. Replace cover.



## Furnace Startup

1. Open the field installed manual gas shut-off valve, and ensure the On/Off gas control valve knob is set to 'On'.
2. Check the inlets to all of the firing tubes on the furnace and ensure that they are all clear of foreign debris. Verify that the tubes line up properly with each nozzle of the gas manifold.
3. Start the unit and check the gas supply pressure at the inlet gas gauge, this gauge is upstream of all electronic gas valves. The inlet pressure should be **7 in. - 14 in. w.c. on natural gas or 11 in. – 14 in. w.c. on propane gas**. If the inlet pressure is too high, install an additional pressure regulator external to the unit.
4. Verify DIP switches are set correctly on the modulating valve. Factory settings are all DIP switches 'OFF'.
5. A final gas leak check shall be performed to verify the gas-tightness of the heater's components and piping under normal operating conditions.
6. At any point during high/low fire burner adjustment, check the characteristics of the flames in every firing tube of the furnace. Non-existence of flame or a lazy flame can be caused by low gas pressure, a dirty nozzle orifice, or clogged section of exhaust flue.
7. When testing is complete, replace all caps and covers removed during the adjustment procedure.

**Table 10 – DIP Switch Position**

DIP Switch Position Table			
Control Signal	SW1 Signal	SW2 Offset	SW3 Characteristic
0-10V	OFF	OFF	OFF
2-10V	OFF	ON	OFF
0-20 mA	ON	OFF	OFF
4-20 mA	ON	ON	OFF

## High Fire Burner Adjustment


1. Set the unit into high fire mode. This is achieved by configuring high fire by going into the [HMI Configuration](#) menu (page 24). **Service>test menu>test heating>run high fire test>stages: all.**
2. After it has been verified that the furnace(s) are lighting off properly, the manifold gas pressure should be adjusted to jobsite conditions. The gas pressure regulator (integral to the On/Off gas control valve) is adjusted at the factory for average gas conditions. It is important that the gas supplied to the furnace is in accordance with the input rating on the rating plate.

See [“Gas Pressure Adjustment Reference Information”](#) (page 39) for an overview of proper pressure settings of all furnaces and for a visual representation of the layout of the furnaces. Once the gas pressure is verified, exit the high fire test.


Once the gas pressure is verified, continue to step 3.

3. If the unit is set up for analog control, continue with high fire using the method above or send the unit a constant 10V DC or 20mA signal. See **Table 10**.
  - o Remove the cover on the modulating valve. Read the manifold gas pressure gauge (0-10 in. w.c.) located directly on the gas manifold. The pressure should read **3.5 in. w.c. for natural gas / 10 in. w.c. for propane**. If the pressure is incorrect, adjust the pressure.

**Figure 22 – ON/Off Gas Valve**



**Figure 23 – Modulating Valve**



- To adjust the pressure, press button #1 until the LED lights solid red. Release the button. The valve is now in high fire setting mode.
- Buttons #1 and #2 are used to set desired high fire setting. Press once to step or hold to auto step.
  - Button #1 = increases flow
  - Button #2 = decreases flow


To save the high fire setting, simultaneously hold buttons #1 and #2 until the LED turns off.

4. If the proper (**in. w.c.**) gas pressure cannot be achieved by adjusting the modulating gas valve, and it has been verified that the inlet gas pressure is within the acceptable range of **7 in. - 14 in. w.c. on natural gas and 11 in. – 14 in. w.c. on propane gas**, adjust the regulator on the On/Off gas control valve.


### Low-Fire Burner Adjustment

1. Lock the unit into low fire mode. This is achieved by configuring low fire by going into the [HMI Configuration](#) menu (page 24). **Service>test menu>test heating>run low fire test**. See **Table 9** for an overview of proper pressure settings.
2. Press and hold button #2 on the modulating valve until the LED light blinks red. Release the button. The valve is now in low fire setting mode.
3. Press button #1 to increase flow or press button #2 to decrease flow.
  - The desired pressure reading for natural gas is **0.15 in. w.c.** If this cannot be obtained, set the low fire pressure as low as possible.
  - The pressure reading for propane gas should be **0.75 in. w.c.**
4. Save the low fire setting by simultaneously holding down buttons #1 and #2 until the blinking LED turns off. Press the abort button on the HMI to exit low fire mode.

**Figure 24 – Modulating Valve Electric Controls**



**Figure 25 – On/Off Gas Valve Regulator**



## Final Start-Up Procedure

1. With the air and burner systems in full operation and all ducts attached, measure the system airflow. The motor sheave (pulley) is variable pitch, and allows for an increase or decrease of the fan RPM. See below Pulley Adjustment section if airflow needs to be adjusted. Refer to **Table 11** and **Table 13** for adjustment specifications.
2. Once the proper airflow is achieved, measure and record the fan speed with a reliable tachometer. **Caution - Excessive speed will result in motor overloading or bearing failure. Do not set fan RPMs higher than specified in the maximum RPM chart.** See the troubleshooting guide for more information.
3. Measure and record the **voltage** and **amperage** to the motor and compare with the motor nameplate to determine if the motor is operating under safe load condition.
4. Once the rpm of the ventilator has been properly set, disconnect power and recheck belt tension and pulley alignment as shown in [Pulley Alignment/Proper Belt Tension](#) (page 44).

**Table 11 – Maximum RPM and HP Chart**

Belt Drive			Direct Drive		
Blower Size	Maximum RPM	Maximum HP	Blower Size	Maximum RPM	Maximum HP
10"	1800	2	15D	1800	2
12"	1500	3	20D	1500	3
15"	1400	5	24D	1400	5
18"	1200	5	30D	1200	5
20"	1000	10	36D	1000	10
25"	900	20	16Z	2400	4
			18Z	3200	5
			20Z	2300	5
			22Z	1900	5
			25Z	1800	8
			28Z	1400	7


## Pulley Adjustment

The adjustable motor pulley is factory set for the RPM specified. Speed can be increased by closing or decreased by opening the adjustable motor sheave. Two groove variable pitch pulleys must be adjusted an equal number of turns or closed. Any increase in speed represents a substantial increase in horsepower required by the unit. Motor amperage should always be checked to avoid serious damage to the motor when the speed is varied. Always torque setscrews according to **Table 12** torque specifications.

**Table 12 - Setscrew Torque**

Thread Size	Torque (IN/LB)
No. 10	32
1/4"	72
5/16"	130
3/8"	275
7/16"	384
1/2"	600

**Figure 26 - Pulley Adjustment Illustration**



Decrease Amperage  
and Blower RPM

# Pulley Alignment/Proper Belt Tension

Figure 27 – Alignment Reference





Figure 28 – Belt Tension



# Pulley Combination Chart

Table 13

Motor RPM		1725														
10 - 20 IN. BLOWER**	<b>1/3 to 1-1/2 HP AX BELTS</b>		MOTOR PULLEY 1VL34		Dd1	Dd2	Pd1	Pd2	TURNS ON MOTOR PULLEY							
			1VL34		1.9	2.9	2	3	Closed							
	BLOWER PULLEY	DATUM DIAMETER	PITCH DIAMETER	5	4 1/2	4	3 1/2	3	2 1/2	2	1 1/2	1	1/2	0		
	AK114	11	11.2	308	323	339	354	370	385	400	416	431	447	462		
	<b>1/3 to 2 HP AX BELTS</b>		MOTOR PULLEY 1VL40		Dd1	Dd2	Pd1	Pd2	TURNS ON MOTOR PULLEY							
			1VL40		2.4	3.4	2.6	3.6	Closed							
	BLOWER PULLEY	DATUM DIAMETER	PITCH DIAMETER	5	4 1/2	4	3 1/2	3	2 1/2	2	1 1/2	1	1/2	0		
	AK114	11	11.2	400	416	431	447	462	477	493	508	524	539	554		
	AK94	9	9.2	488	506	525	544	563	581	600	619	638	656	675		
	AK79	7.5	7.7	582	605	627	650	672	694	717	739	762	784	806		
	AK66	6.2	6.4	701	728	755	782	809	836	863	889	916	943	970		
	AK54	5	5.2	863	896	929	962	995	1028	1062	1095	1128	1161	1194		
	AK46	4.2	4.4	1019	1059	1098	1137	1176	1215	1255	1294	1333	1372	1411		
	AK39	3.5	3.7	1212	1259	1305	1352	1399	1445	1492	1539	1585	1632	1678		
AK32	3	3.2	1402	1455	1509	1563	1617	1671	1725	1779	1833	1887	1941			
<b>3 to 5 HP BX BELTS</b>		MOTOR PULLEY 2VP42		Dd1	Dd2	Pd1	Pd2	TURNS ON MOTOR PULLEY								
		2VP42		2.9	3.9	3	4	Closed								
BLOWER PULLEY	DATUM DIAMETER	PITCH DIAMETER	6	5 1/2	5	4 1/2	4	3 1/2	3	2 1/2	2	1 1/2	1	1/2	0	
2BK160H	15.4	15.7	330	339	348	357	366	375	385	394	403	412	421	430	439	
2BK140H	13.4	13.7	378	388	399	409	420	430	441	451	462	472	483	493	504	
2BK120H	11.4	11.7	442	455	467	479	491	504	516	528	541	553	565	577	590	
2BK110H	10.4	10.7	484	497	511	524	537	551	564	578	591	605	618	631	645	
2BK100H	9.4	9.7	534	548	563	578	593	608	622	637	652	667	682	697	711	
2BK90H	8.4	8.7	595	611	628	644	661	677	694	710	727	744	760	777	793	
2BK80H	7.4	7.7	672	691	709	728	747	765	784	803	821	840	859	877	896	
2BK70H	6.4	6.7	772	794	815	837	858	880	901	923	944	965	987	1008	1030	
2BK60H	5.4	5.7	908	933	958	984	1009	1034	1059	1084	1110	1135	1160	1185	1211	
2BK55H	4.9	5.2	995	1023	1050	1078	1106	1133	1161	1189	1216	1244	1272	1299	1327	
2BK50H	4.4	4.7	1101	1132	1162	1193	1223	1254	1285	1315	1346	1376	1407	1438	1468	
<b>7-1/2 to 10 HP BX BELTS</b>		MOTOR PULLEY 2VP60		Dd1	Dd2	Pd1	Pd2	TURNS ON MOTOR PULLEY								
		2VP60		4.3	5.5	4.7	5.9	Closed								
BLOWER PULLEY	DATUM DIAMETER	PITCH DIAMETER	6	5 1/2	5	4 1/2	4	3 1/2	3	2 1/2	2	1 1/2	1	1/2	0	
2BK160H	15.4	15.7	516	527	538	549	560	571	582	593	604	615	626	637	648	
2BK140H	13.4	13.7	592	604	617	630	642	655	667	680	693	705	718	730	743	
2BK120H	11.4	11.7	693	708	722	737	752	767	781	796	811	826	840	855	870	
2BK110H	10.4	10.7	758	774	790	806	822	838	854	871	887	903	919	935	951	
2BK100H	9.4	9.7	836	854	871	889	907	925	943	960	978	996	1014	1031	1049	
2BK90H	8.4	8.7	932	952	972	991	1011	1031	1051	1071	1091	1110	1130	1150	1170	
2BK80H	7.4	7.7	1053	1075	1098	1120	1143	1165	1187	1210	1232	1255	1277	1299	1322	
25 IN. BLOWER	<b>3 to 5 HP BX BELTS</b>		MOTOR PULLEY 2VP42		Dd1	Dd2	Pd1	Pd2	TURNS ON MOTOR PULLEY							
			2VP42		2.9	3.9	3	4	Closed							
	BLOWER PULLEY	DATUM DIAMETER	PITCH DIAMETER	6	5 1/2	5	4 1/2	4	3 1/2	3	2 1/2	2	1 1/2	1	1/2	0
	2BSV278	27.8	28.1	184	189	194	200	205	210	215	220	225	230	235	240	246
	2BSV250	25	25.3	205	210	216	222	227	233	239	244	250	256	261	267	273
	2BSV234	23.4	23.7	218	224	230	237	243	249	255	261	267	273	279	285	291
	2BSV200	20	20.3	255	262	269	276	283	290	297	304	312	319	326	333	340
	2BSV184	18.4	18.7	277	284	292	300	307	315	323	331	338	346	354	361	369
	2BSV160	16	16.3	317	326	335	344	353	362	370	379	388	397	406	414	423
	2BSV154	15.4	15.7	330	339	348	357	366	375	385	394	403	412	421	430	439
	2BSV136	12.6	12.9	401	412	423	435	446	457	468	479	490	501	513	524	535
	2BSV124	12.4	12.7	407	419	430	441	453	464	475	487	498	509	521	532	543
	2BSV110	11	11.3	458	471	483	496	509	522	534	547	560	572	585	598	611
	<b>7-1/2 to 10 HP BX BELTS</b>		MOTOR PULLEY 2VP60		Dd1	Dd2	Pd1	Pd2	TURNS ON MOTOR PULLEY							
		2VP60		4.3	5.5	4.7	5.9	Closed								
BLOWER PULLEY	DATUM DIAMETER	PITCH DIAMETER	6	5 1/2	5	4 1/2	4	3 1/2	3	2 1/2	2	1 1/2	1	1/2	0	
2BSV278	27.8	28.1	289	295	301	307	313	319	325	331	338	344	350	356	362	
2BSV250	25	25.3	320	327	334	341	348	355	361	368	375	382	389	395	402	
2BSV234	23.4	23.7	342	349	357	364	371	378	386	393	400	408	415	422	429	
2BSV200	20	20.3	399	408	416	425	433	442	450	459	467	476	484	493	501	
2BSV184	18.4	18.7	434	443	452	461	470	480	489	498	507	517	526	535	544	
2BSV160	16	16.3	497	508	519	529	540	550	561	571	582	593	603	614	624	
2BSV154	15.4	15.7	516	527	538	549	560	571	582	593	604	615	626	637	648	
2BSV136	12.6	12.9	628	642	655	669	682	695	709	722	735	749	762	776	789	
2BSV124	12.4	12.7	638	652	666	679	693	706	720	733	747	761	774	788	801	
2BSV110	11	11.3	717	733	748	763	779	794	809	824	840	855	870	885	901	
<b>15 to 20 HP BX BELTS</b>		MOTOR PULLEY 2VP75		Dd1	Dd2	Pd1	Pd2	TURNS ON MOTOR PULLEY								
		2VP75		5.8	7	6.2	7.4	Closed								
BLOWER PULLEY	DATUM DIAMETER	PITCH DIAMETER	6	5 1/2	5	4 1/2	4	3 1/2	3	2 1/2	2	1 1/2	1	1/2	0	
2BSV278	27.8	28.1	381	387	393	399	405	411	417	424	430	436	442	448	454	
2BSV250	25	25.3	423	430	436	443	450	457	464	470	477	484	491	498	505	
2BSV234	23.4	23.7	451	459	466	473	480	488	495	502	509	517	524	531	539	
2BSV200	20	20.3	527	535	544	552	561	569	578	586	595	603	612	620	629	
2BSV184	18.4	18.7	572	581	590	600	609	618	627	636	646	655	664	673	683	
2BSV160	16	16.3	656	667	677	688	698	709	720	730	741	751	762	773	783	
2BSV154	15.4	15.7	681	692	703	714	725	736	747	758	769	780	791	802	813	
2BSV136	12.6	12.9	829	842	856	869	883	896	909	923	936	949	963	976	990	

\*\* 2HP Motors on 20 IN Blowers use 2VP42 Pulleys

## High Altitude Orifice Sizing

The burner orifices should be sized per the table below depending on fuel type, furnace size and altitude. Standard orifice sizes are for sea level. The unit should either be ordered with the altitude specific orifices or the parts should be ordered through the manufacturer.

**Table 14 – High Altitude**

Natural Gas High ALT Conversion						
High ALT for 400,000BTU			High ALT for 300,000 to 75,000BTU			
Altitude	Input Rate	Drill Size	Input Rate	Input Rate	Input Rate	Drill Size
0 - 1999ft	400000	#41	300,000	200,000	150,000	#3/32
2000-2999ft	384000	#42	288000	192000	144000	2.35mm
3000-3999ft	368640	2.35mm	276480	184320	138240	2.3mm
4000-4999ft	353894	2.3mm	265421	176947	132710	#43
5000-5999ft	339739	#43	254804	169869	127402	2.25mm
6000-6999ft	326149	2.25mm	244612	163075	122306	#44
7000-7999ft	313103	#44	234827	156552	117414	2.15mm
8000-8999ft	300579	#45	225434	150290	112717	#46
9000-10000ft	288556	#46	216417	144278	108209	#47

LP Gas High ALT Conversion						
High ALT for 400,000BTU			High ALT for 300,000 to 75,000BTU			
Altitude	Input Rate	Drill Size	Input Rate	Input Rate	Input Rate	Drill Size
0 - 1999ft	400000	1.45mm	300,000	200,000	150,000	#54
2000-2999ft	384000	#54	288000	192000	144000	#54
3000-3999ft	368640	#54	276480	184320	138240	#55
4000-4999ft	353894	#54	265421	176947	132710	#55
5000-5999ft	339739	#54	254804	169869	127402	#55
6000-6999ft	326149	#55	244612	163075	122306	#55
7000-7999ft	313103	#55	234827	156552	117414	#56
8000-8999ft	300579	#55	225434	150290	112717	#56
9000-10000ft	288556	#56	216417	144278	108209	#57

Orifice Part Numbers		
Size	Part#	AX#
#41	BG100-41	A0023045
#42	BG100-42	A0023050
2.35mm	BG101-19	A0023053
2.3mm	BG101-05	A0023051
#43	BG100-43	A0023047
2.25mm	BG101-20	A0023054
#44	BG100-44	A0023046
#45	BG100-45	A0028800
#46	BG100-46	A0028801
#47	BG100-47	A0028802
#3/32	BG100-3/32	A0023044
2.15mm	BG101-21	A0023055
1.45mm	BG101-16	A0023052
#54	BG100-54	A0023048
#55	BG100-55	A0023049
#56	BG100-56	A0023057
#57	BG100-57	A0028803

Orifice Qty. Per Furnace	
Size	Qty
150,000 BTU	6
200,000 BTU	8
300,000 BTU	12
400,000 BTU	15

## Sequence of Operation (Summary)

- Main Blower is turned “On” and the Main Airflow Switch is proven.
- Air temperature at the intake of the unit falls below the setting of the Intake Air Set-point initiating a “Call for Heat” to the IBT Board.
- FSC-1 sends 24V AC power back to the IBT Board.
- IBT BOARD sends a 120V AC signal to Power-vent Blower Motor to initiate 1 min pre-purge at high speed.
- 24V AC signal runs through the safety circuit (Power-vent Airflow Switch/High Temperature Limit/Flame Roll-out Switch) and into FSC-1.
- FSC-1 initiates Trial for Ignition by sending signal to Spark Igniter to light furnace and 24V AC power to On/Off Gas Valve and signal to IBT BOARD that it is sparking. This opens On/Off Gas Valve and triggers the start of the 17 seconds of 10V DC from the IBT BOARD to the modulating valve(s) and 120V AC output to the Power-vent Blower Speed Controller(s).
- Flame is sensed by FSC-1’s Remote Flame Sensor at the upper-most firing tube of furnace.
- IBT BOARD’s 17 second high-fire sequence runs out and 0-10V DC modulating signal from IBT BOARD is output to Modulating Gas Valve and modulates the Power-vent Blower Speed Controller along with the modulating gas valves to maintain efficiency.
- IBT BOARD continues to modulate the heat output of MAU by adjusting the 0-10V DC signal to Modulating Gas Valve and turning other modulating furnaces or On/Off Staged Furnaces on and off as required to satisfy the Temperature Selector Dial setting.

Note: If two modulating furnaces are present this sequence occurs with FSC-2 and a second speed controller if the call for heat dictates a need for a second furnace.

## Sequence of Operation (Detailed)

The Indirect-fired heater is most easily understood when broken down into smaller individual systems. There are two main systems; a make-up air fan and a heater. The make-up air fan consists of a heavy-duty blower and motor. The heater may be further broken down into two control systems, the Modulating Gas System (MGS) and the Flame Safety Control (FSC). The burner mixes air with the gas (Natural or Propane) which burns into a heat exchanger which heats the air. There are between one and four furnaces in each heater depending on the total required heating output capacity for the application. Included in every unit is at least one modulating furnace, located furthest downstream, closest to the discharge of the heating module. The modulating furnace(s) and additional On/Off furnaces (if used) are controlled using vernier-type modulation methods resulting in fully linear heating output over the entire gas-firing range.

## Modulating Gas System


The first system, the **Modulating Gas System**, consists of an Intake Air Sensor, a Vernier Auto Balancing Module (IBT Board), a Discharge Air Sensor, a Space Air Sensor (only on space temp control option), and a modulating gas valve(s). The Intake Air Sensor, the space sensor, or a combination of the two can be used to give a call for heat signal to the IBT board. Using a PID loop, the IBT board looks at the difference between the temp sensor readings in order to appropriately modulate the heat. For Kitchen MUA heating applications, Intake Air setpoint should be set at 45°F, whereas the discharge setpoint should be set at 55°F. For all other applications, the setpoint should be set appropriately based on the end-users preferences and on-site conditions.

There are 4 different options for controlling the gas firing output of these units. These include Discharge Temperature Control, Space Temperature Control, and Building Automation Control, and DDC. Refer to [HMI Menu Description](#) (page 25) to see where the menu items are located to configure for each type of control:

1. **Discharge Control:** When used in discharge control, the IBT board receives a call to heat from the intake sensor, the IBT board will modulate the discharge temperature until it hits the desired set point. The user can choose whether discharge heating/cooling is activated based on intake temperature, space temperature, either, or both.
2. **Space Control:** When the space control option has been selected, there will be an HMI that contains an internal temperature sensor. The user can choose whether the space heating/cooling is activated based on intake temperature, space temperature, either, or both.
3. **Analog Control/Direct Digital Control (DDC):**  
A 0-10V DC or 0-20mA signal is sent to the IBT board from the building control system to regulate the heating output of the unit. Refer to Appendix B for BACNET/LONWORK DDC points. If Analog Control is utilized, dipswitch 4 on the IBT board should be set to up (main and slave if 2 IBT boards are present).

In all cases, the IBT board controls the amount of gas to the burner based on the signal from the temperature control components. When the modulating gas valve is all the way open and achieving the maximum BTUs and temperature rise of the unit, it is called “high fire”.


**Figure 29 - Temp Sensor**



## Flame Safety Control

The second system to understand is the **Flame Safety Control**. The FSC is present **only** to monitor the flame, NOT to control temperature. The FSC uses a sensor mounted at the intake of the upper-most firing tube of the furnace to sense the existence of a flame. The FSC controls the opening of the redundant solenoid gas valves and the operation of the spark igniter to initiate a flame upon start up. When there is a call for heat, the LED on the FSC is energized indicating that the unit has power. Then, there is a one minute pre-purge in which the power-vent blower on the furnace runs at full speed to exhaust any gas in the Heat-exchanger/Control Cabinet that may be present prior to trial for ignition. As soon as the pre-purge has initiated, the FSC checks that airflow is sensed by the power-vent airflow switch\* and that the High Limit and Roll-out switches are not tripped.

**Figure 30 - Flame Safety Controller**



**\*NOTE: If, while trouble-shooting the unit, it is necessary to jumper-out this airflow switch, the jumpers must be applied to the contacts immediately after the power-vent motor is turned on and the FSC begins to check for airflow, otherwise the unit will go into lock-out mode.**

Upon successful sensing of induced power-vent airflow and continuity of temperature limit and roll-out switches, the FSC initiates a 15 second ignition sequence. During this ignition sequence, the FSC opens the On/Off gas valves and allows gas to pass through to the gas manifold. At the same moment, the spark igniter begins to spark, causing the electrode on the burner to ignite the gas. This results in a flame at the lowest firing tube of the furnace which immediately ignites the flow of gas in each succeeding firing tube moving vertically until the entire furnace is lit. When the sensor detects the flame at the intake of the upper-most firing tube the FSC continues to power the On/Off gas valve until there is a loss of flame presence. This is the normal operating mode.

**Figure 31 – Ignition Sequence**

### Flame Safety Ignition Sequence

Interval Description:	Initial Call for Heat	1 Min. Pre-purge	15 Sec. Trial for Ignition	1 Min. Inter-purge	15 Sec. Trial for Ignition	1 Min. Inter-purge	15 Sec. Trial for Ignition	2 Min. Post-purge	1 hr Lockout	Repeat Cycle
Time(Min:Sec):	0:00	1:00	1:15	2:15	2:30	3:30	3:45	5:45	End of Cycle	
(Non-Linear Scale)										

## Modulating Stage Sequence

As mentioned in the previous sections, every unit is equipped with a modulating furnace(s) located furthest downstream at the discharge of the heater module. The modulating stage(s) operates differently than the other On/Off staged furnaces in that instead of being “On” or “Off”, the gas flow to this furnace is modulated up and down to account for varying calls for heat during the unit’s operating period. In addition, the speed of its power-vent blower is varied as the gas flow changes in order to maintain constant combustion efficiency over the entire firing range.

Modulating furnace power-vent blower(s) are controlled by an onboard speed controller on the IBT that varies the output voltage to the motor. There is one Speed Controller per modulating furnace. (Two speed controllers per board.) The Output voltage (True RMS) to the motor varies non-linearly between 120V AC @ 10V DC for high fire and 81.6V AC @ 0V DC for low fire.

## **IBT BOARD and High Fire Start**

The IBT BOARD translates a difference between two sensor values and the set point or a 0-10V DC or 0-20 mA signal from an Analog Control to the modulating furnace(s). The signal is linearized such that input voltage is directly proportional to amount of gas being delivered to the modulating valve(s). If that signal is greater than a high voltage threshold for a certain interval it will relay 24V to the FSC on the next furnace. This will repeat if the heat capacity is still not enough and more stages will be turned on. If the call for heat is lower than a low voltage threshold for a certain period of time the IBT BOARD will cut power to the last stage that turned on, starting the post purge sequence and repeat the process for subsequent stages if needed. On furnaces that have two modulating burners the linearized signal is sent to one of these burners depending on the need for heat while the furnace not receiving the modulating signal is locked in to high fire, low fire or off.

In order to ensure proper light-off in all conditions, every unit's IBT BOARD contains software that forces the modulating furnace(s) to light at high fire when that furnace's main gas valve is first opened. There is a built in timer that allows it to send a constant 10V DC signal to the modulating gas valve(s) and power-vent blower speed controller(s) and force the furnace(s) into high fire for a period of 17 seconds after the initial spark is sent by the FSC. After this forced high-fire light-off period has expired, the modulating furnace's power-vent blower and modulating gas valve will receive a modulating signal from the IBT BOARD as mentioned above.

**NOTE:** For in-depth board information, see [Appendix A](#) (page 72)

## **Re-Circulating Control Options**

### **Manual Positioning Control**

The dampers can be controlled from the HMI in the unit or from a space HMI if one is provided to any position from 0% to 100% fresh air. This is a 0-10V setting, which is available under user settings, 100% Outdoor Air (0 volts), 100% Return Air (10 volts). This will allow manually setting the dampers to match the building ventilation requirements. On a power failure the return air damper will close by spring return.

### **Two Position Control**

The dampers can be controlled by a two position switch (a field supplied switching device) to open the fresh air to 100%. The IBT board sends out a constant voltage. The field supplied switch will cut or allow the signal from the IBT board to the mixing box damper. On opening of the circuit, power failure, or if the unit is shutoff, the return air damper will close by spring return. If the circuit is closed, the IBT board will allow the return air damper to open per the set point.

### **Outdoor Air %**

The dampers can be controlled from the HMI in the unit or from a space HMI if one is provided to any position from 0% to 100% fresh air. There is an outdoor air percentage setting which is available under user settings. This will allow the user to manually set the dampers to match the building ventilation requirements. The IBT board utilizes an internal algorithm to alter its 0-10V output to the mixing box damper in order to maintain an exact outdoor air percentage. When this mixing box option is selected, a mixing box deadband comes into play. This setting checks the delta T between outdoor and return air. If the difference between these two temperatures is less than or equal to the mixing box deadband setting, the IBT board will not alter its output to the mixing box damper (default setting is 5 degrees). On a power failure, or if the unit is turned off, the return air damper will close by spring return.

## Static Pressure Control (Photohelic)

The dampers can be controlled by a building static pressure control. This controller will sense the difference between pressure inside the building, and pressure outside the building (sensed at the A306 outdoor sensor), and position the dampers to maintain the pressure setting on the controller. The controller has two set points and an indicator. The two set points are a minimum desired static pressure point, and a maximum static pressure point.

The actual building static pressure will be shown by a visual indicator between these two settings. The controller will modulate the dampers to maintain a static pressure between these set points.

When building static pressure is below the minimum setting, the damper motor will proportionally open the fresh air damper and close the return air damper until static increases above the minimum setting. At this point, the damper motor will stop and hold this proportion.

If the building static continues to climb and goes above maximum setting, the damper motor will reverse proportion, closing the fresh air damper and opening the return air damper until static drops below maximum setting.

During the "OFF" or "Night" cycle of the unit, an internal switching circuit will close the return air damper.

See additional wiring and installation information on the static pressure controller and A306 outdoor sensor.

## Static Pressure Controller Installation Instructions

Avoid locating the front of the static pressure controller in sunlight or other areas with high ambient light or corrosive levels. Bright light shining on the photocells can cause false actuation of the load relays.

The static pressure controller should be zeroed out before attaching the low and high pressure hoses. The zero adjustment is located between the minimum and maximum dials.

Use the supplied rubber tubing the high side of the static pressure controller should be plumbed to the inside of the building. The low side of the static pressure controller should be plumbed to the A306 outdoor sensor. See the A306 installation instructions.

Figure 32 – Photohelic Gauge





Figure 33 – Static Pressure Controller




51

## A306 Outdoor Sensor


The A306 sensor is used in conjunction with the photohelic. Use the installation instructions shipped with the A306 outdoor sensor.

**Figure 34 – Exploded View**

PART #	DESCRIPTION
1	(2) NO. 10-32 X 1/2" MACHINE SCREW
3	(4) NO. 10-32 NUT
4	(2) NO. 10-32 X 1 3/4" MACHINE SCREW
028	ANTENA CLAMP
029	MOUNTING BRACKET
163	PICK UP BODY
164	STATIC PRESSURE PLATES
165	"O" RING SEAL
168	HOLE PLUG
290	TUBING 50 FT



**Figure 35 – Outdoor Sensor Installed**



## Building Signal Damper Control

When this option is ordered, the supply and return dampers will modulate based on a 0-10V DC signal from the Building automation system.

## Schedule Control

When this option is ordered, the supply and return damper will change based on the schedule. There are separate occupied and unoccupied outdoor air percentage settings located under user settings. The unit will maintain the appropriate outdoor air percentage based on the schedule state. When this mixing box option is selected, a mixing box deadband comes into play. This setting checks the delta T between outdoor and return air. If the difference between these two temperatures is less than or equal to the mixing box deadband setting, the IBT board will not alter its output to the mixing box damper (default setting is 5 degrees).

## Network

For DDC descriptions, see [Appendix B – IBT DDC Points](#) (page 76)

**NOTE: The board will reboot when altering factory settings.**


### BACNET

BACNET IP or BACNET MS/TP compatibility can be implemented with this package through a Protoceptor, which is a BTL listed embedded Gateway configured to give a Building Management System (BMS) access to monitor and/or control a list of BACNET objects. The Protoceptor is mounted and factory pre-wired inside the Electrical Control Panel. Field connections to the Building Management System are shown to the right.


The Protoceptor is pre-configured at the factory to use the field protocol of the Building Management System in the specific jobsite. BACNET objects can only be accessed through the specified port and protocol.

1. Field Ethernet Connection for BACNET IP
2. Field RS485 Connection for BACNET MS/TP

**Figure 36 - BACNET Wiring Reference**



**Figure 37 - BACNET Connections**



### Changing Device Instance, MAC Address, Baud Rate


Some applications may require that the Processor have a specific Device Instance, the default device instance is 50,000. To change the Device Instance, you must access the Web Configurator by connecting a computer to the Ethernet port of the Processor. The computer used must be assigned a static IP address of 192.168.1.xxx and a subnet mask of 255.255.255.0.

To access the Web Configurator, type the IP address of the Processor in the URL of any web browser. The default IP address of the Processor is 192.168.1.24. Once the landing page has loaded, if required, log in using "admin" for the username and password. If the default "admin" password does not work, the gateway should have a printed password on the module's Ethernet port.

Go to the main configuration page, select "Configure" from the left-hand menu. Select "Profile Configuration," the window shown in **Figure 38** should appear.

The MAC address and Baud Rate, used by BACNET MTSP, are editable. The MAC address default is 127, and the Baud Rate default is 38400.

**Figure 38 - Configuration Parameters Page**



The screenshot shows the 'Configuration Parameters' page. At the top left is the 'smc sierra monitor' logo. Below the title is a table with four rows of configuration parameters. Each row includes a parameter name, a description, a value field, and a submit button.

Parameter Name	Parameter Description	Value
bac_device_id	<b>BACnet Device Instance</b> This sets the BACnet device instance. (1 - 4194303)	50177 <input type="button" value="Submit"/>
bac_mac_addr	<b>BACnet MSTP Mac Address</b> This sets the BACnet MSTP MAC address. (1 - 127)	7 <input type="button" value="Submit"/>
bac_baud_rate	<b>BACnet MSTP Baud Rate</b> This sets the BACnet MSTP baud rate. (9600/19200/38400/76800)	76800 <input type="button" value="Submit"/>
bac_max_master	<b>BACnet MSTP Max Master</b> This sets the BACnet MSTP max master. (1 - 127)	127 <input type="button" value="Submit"/>

If any changes are made, **click on the submit button for each individual change.** Each individual change will require the system to restart.

## Changing the IP Address

Some BACNET IP applications may require changing the IP address of the Processor. In order to change the IP address, go to the internal server by typing the default IP address of the Processor, 192.168.1.24, in the URL field of any web browser. The computer used must have a static IP address of 192.168.1.xxx. The window shown in **Figure 39** appears. Click on the “Diagnostics and Debugging” button on the lower right corner.

Click on “Setup” from the left hand side menu and select “Network Settings.” The window shown in **Figure 39** will appear. You can now modify the IP address to whatever is required in the application. Once the IP address has been modified, click on “Update IP Settings.”

**Figure 39 - Network Settings Page**


The screenshot displays the Network Settings page of the SMC web configurator. On the left, a navigation menu lists options like 'About', 'Setup', 'File Transfer', 'Network Settings', 'Passwords', 'View', and 'User Messages'. The 'Network Settings' section is active, showing a 'Note' that settings only take effect after a system restart. Below the note is a form for configuring network parameters: N1 IP Address (192.168.1.24), N1 Netmask (255.255.255.0), N1 DHCP Client State (DISABLED), N1 DHCP Server State (DISABLED), Default Gateway (192.168.1.1), Domain Name Server1 (0.0.0.0), and Domain Name Server2 (0.0.0.0). 'Cancel' and 'Update IP Settings' buttons are provided. A 'MAC Address' section shows the N1 MAC Address as 00:50:4E:10:07:27. At the bottom of the page, there are buttons for 'Home', 'HELP (F1)', 'Contact Us', and 'System Restart'.

After you have updated the IP settings, you will be prompted to restart the system. You can do so by clicking on the “System Restart” button at the bottom of the screen. Any time after this, you will have to type the new IP address of the Processor on the URL to gain access to the Web Configurator.

## LonWorks

LonWorks compatibility can be implemented on control packages through the ProtoNode, a LonMark certified external Gateway configured to give a Building Management System access to monitor and/or control a list of Network Variables. The ProtoNode is mounted and factory pre-wired inside the Electrical Control Panel. Field connections to the Building Management System is shown.


**Figure 40 – LonWorks Adapter and Wiring Reference**



## Commissioning on a LonWorks Network

During the commissioning process by the LonWorks administrator (using a LonWorks Network Management Tool), the user will be prompted to hit the Service Pin in the ProtoNode. This pin is located in the front face, and it can be pressed by inserting a small screwdriver and tilting it towards the LonWorks Port. The location of the “Service Pin” is shown in **Figure 41**.

**Figure 41 - Service Pin Location**



**NOTE: Insert Small Screwdriver. Tilt Toward LonWorks Port To Activate Service Pin.**



If an XIF file is required, it can be obtained by following these steps:

1. Set your computer's static IP address to 192.168.1.xxx with a subnet mask of 255.255.255.0.
2. Run a Cat 5 connection from the ProtoNode's Ethernet port to your computer.
3. On any web browser's URL field, type 192.168.1.24/fserver.xif

The web browser should automatically download the fserver.xif file or let you save it on your computer. Save it as fserver.xif.

# SERVICE INFORMATION

## Troubleshooting Flow-charts



## Fault Codes

The following tables list causes and corrective actions for possible problems with indirect heater units. Review these lists prior to consulting technical support.

Fault	Description	Possible checks
Fire	There is an input from the fire detector.	<ul style="list-style-type: none"> <li>• Check for short circuits in the wire.</li> <li>• Replace fire detector.</li> </ul>
Smoke	There is an input from the smoke detector.	<ul style="list-style-type: none"> <li>• Verify the smoke detector is set up properly.</li> <li>• Check for short circuits in the wire.</li> <li>• Replace smoke detector.</li> </ul>
Gas PS High	The board is receiving an input on the gas pressure high terminal.	<ul style="list-style-type: none"> <li>• Adjust regulator or add regulator.</li> <li>• Repair faulty wiring.</li> <li>• Replace switch.</li> <li>• See <a href="#">High Gas Pressure switch</a> (page 65).</li> </ul>
Gas PS Low	The board lost input on the Gas Pressure Low terminal. There should be an input when gas pressure is at the proper level.	<ul style="list-style-type: none"> <li>• Low Gas pressure switch.</li> <li>• Repair broken or loose wiring connections.</li> <li>• Replace switch.</li> <li>• See <a href="#">Low Gas Pressure switch</a> (page 65).</li> </ul>
Exhaust Overload	Motor overload has tripped.	<ul style="list-style-type: none"> <li>• Check motor for debris or bad bearings.</li> <li>• Check motor wiring connections.</li> <li>• Check overload reset button.</li> <li>• Check wiring to the contactor.</li> <li>• Check overload amperage setting.</li> </ul>
Supply Overload	Motor overload has tripped.	<ul style="list-style-type: none"> <li>• Check motor for debris or bad bearings.</li> <li>• Check motor wiring connections.</li> <li>• Check overload reset button.</li> <li>• Check wiring to the contactor.</li> <li>• Check overload amperage setting.</li> </ul>
Sensor missing (Return, Outside, Intake, Discharge)	Temperature sensor is not connected	<ul style="list-style-type: none"> <li>• Install, and wire sensor.</li> <li>• Check for faulty wiring.</li> <li>• See <a href="#">temperature sensor</a> (page 64).</li> </ul>
Sensor broken (Return, Outside, Intake, Discharge)	Temperature sensor is defective	<ul style="list-style-type: none"> <li>• Check for faulty wiring.</li> <li>• See <a href="#">temperature sensor</a> (page 64).</li> </ul>
HMI Temp Sensor	The HMI contains an internal temperature sensor.	<ul style="list-style-type: none"> <li>• Verify there is no damage to the HMI, or wiring to HMI.</li> <li>• If space temperature is being utilized, make sure HMI Averaging is set to ON for all space HMIs. Refer to <a href="#">HMI Menu Tree</a> (page 30) Factory Settings – Unit Options.</li> </ul>
RTC 1 Temp Sensor	Real Time Clock (RTC) temperature sensor located on IBT board.	<ul style="list-style-type: none"> <li>• Verify there is no damage to the IBT board.</li> <li>• Check wiring to the IBT board.</li> </ul>

Fault	Description	Possible checks
No supply air proving (Air flow switch)	Signal was not received from air switch when supply blower was running.	<ul style="list-style-type: none"> <li>• Make sure the blower runs.</li> <li>• Check air switch wiring.</li> <li>• Check blower rotation.</li> <li>• Check damper operation.</li> <li>• See <a href="#">Air Flow Switch</a> (page 63).</li> </ul>
FSC1 High Temp	The Flame Sensor Controller (FSC) continually and safely monitors, analyze, and controls the proper operation of the gas burner and inducer motor.	<ul style="list-style-type: none"> <li>• Check connector J7 on the IBT board. Make sure the connection is secure.</li> <li>• High limit switch failed open. There should be continuity.</li> </ul>
FSC1 Rollout	If flame-rollout is present, the switch de-energizes heater circuit on individual furnace. Must be manually reset by pressing small button on the switch. 325°F set-point.	<ul style="list-style-type: none"> <li>• Check wiring to the switches</li> <li>• Reset the switch.</li> <li>• Rollout switch failed open. There should be continuity.</li> <li>• Check for a blocked tube, low airflow, or low gas pressure.</li> </ul>
FSC Vent Proving	The FSC verifies that airflow is sensed by the induced draft air sensor.	<ul style="list-style-type: none"> <li>• Kinked/blocked/damaged hose.</li> <li>• Poor venting.</li> <li>• Blockage in vent system.</li> <li>• Clogged condensation drain.</li> <li>• Power vent motor.</li> <li>• Failed switch.</li> <li>• See <a href="#">Vent Proving switch</a> (page 64).</li> </ul>
Freezestat lockout	The discharge temperature was too low for a long period of time.	<ul style="list-style-type: none"> <li>• Check gas pressure.</li> <li>• Check for proper burner firing.</li> <li>• Use the HMI to reset.</li> </ul>
Firestat lockout	Intake or discharge temperatures exceeded the firestat set point.	<ul style="list-style-type: none"> <li>• Use the HMI to reset.</li> <li>• Check for faulty regulators.</li> <li>• Check for faulty modulating valves.</li> </ul>
DX Float detect	Input signal from the drain pan float switch	<ul style="list-style-type: none"> <li>• Make sure the pan drain is clear and water is draining.</li> <li>• Check for shorted wires.</li> <li>• Replace float switch.</li> </ul>
Modbus system communication	Software mismatch	Contact technical support.
Master ROM CRC	Software mismatch	Contact technical support.
Clogged filters	Input from filter airflow switch.	<ul style="list-style-type: none"> <li>• Clean or replace filters.</li> <li>• See <a href="#">Clogged Filter Switch</a> (page 63).</li> </ul>
Check FPKD	Freeze Protection Drain Kit is not operating correctly.	<ul style="list-style-type: none"> <li>• Improper installation.</li> <li>• Not Installed.</li> </ul>
HMI "x" Revision Wrong	Software mismatch	Contact technical support to flash the appropriate software.
HMI Config Error	HMI is not connected, or HMI is assigned incorrectly	Install HMI or change HMI address using bottom 2 buttons on HMI. See <a href="#">HMI Options Screen</a> (page 25)

## Airflow Troubleshooting Chart

Problem	Potential Cause	Corrective Action
Fan Inoperative	<ul style="list-style-type: none"> <li>Blown fuse</li> <li>Open circuit breaker</li> </ul>	<ul style="list-style-type: none"> <li>Check amperage.</li> <li>Check fuse, replace if needed.</li> <li>Check circuit breaker.</li> </ul>
	Disconnect switch in "Off" position	Turn to "On" position.
	Motor wired incorrectly	Check motor wiring. Verify connections with wiring diagram located on fan motor.
	Broken fan belt	Replace belt.
	Motor starter overloaded	<ul style="list-style-type: none"> <li>Check amperage.</li> <li>Reset starter.</li> </ul>
	HMI set to "Blower Off"	Set HMI to "Blower On".
Motor Overload	Fan rotating in the wrong direction	Verify the fan is rotating in the direction shown on rotation label.
	Fan speed is too high	Reduce fan RPM.
	Motor wired incorrectly	Check motor wiring. Verify connections with wiring diagram located on fan motor.
	Overload in starter set too low	Set overload to motor FLA value.
	Motor HP too low	Determine if HP is sufficient for job.
	Duct static pressure lower than design	Reduce fan RPM.
Insufficient Airflow	Fan rotating in the wrong direction	Verify the fan is rotating in the direction shown on rotation label.
	Poor outlet conditions	There should be a straight clear duct at the outlet.
	Intake damper not fully open	Inspect damper linkage. If the linkage is damaged, replace damper motor.
	Duct static pressure higher than design	Improve ductwork to eliminate or reduce duct losses.
	Blower speed too low	Increase fan RPM. Do not overload motor.
	Supply grills or registers closed	Open and adjust.
	Dirty/clogged filters	Clean filters. Replace filters if they cannot be cleaned or are damaged.
	Belt slippage	Adjust belt tension.
Excessive Airflow	Blower speed too high	Reduce fan RPM.
	Filters not installed	Install filters.
	Duct static pressure lower than design	Reduce fan RPM.
Excessive Vibration and Noise	Misaligned pulleys	Align pulleys.
	Damaged/unbalanced wheel	Replace wheel.
	Fan is operating in the unstable region of the fan curve	Refer to performance curve for fan.
	<ul style="list-style-type: none"> <li>Bearings need lubrication</li> <li>Damaged bearing</li> </ul>	<ul style="list-style-type: none"> <li>Lubricate bearings.</li> <li>Replace bearings if damaged.</li> </ul>
	Fan speed is too high	Reduce fan RPM.
	<ul style="list-style-type: none"> <li>Dirty/oily belt</li> <li>Belts too loose</li> <li>Worn belt</li> </ul>	<ul style="list-style-type: none"> <li>Clean belts.</li> <li>Inspect and replace if needed.</li> </ul>

## Furnace Troubleshooting Chart

Problem	Potential Cause	Corrective Action
Furnace Does Not Light/Stay Lit	Main gas is off	Open main gas valve.
	Air in gas line	Purge gas line.
	Dirt in burner orifices	Clean orifices with compressed air.
	Gas pressure out of range	Adjust to proper gas pressure.
	ON/OFF gas valve is off	Turn ON/OFF gas valve on.
	Spark Igniter Rod out of position	Relocate Spark Igniter Rod to proper area.
	Excessive drafts	Re-direct draft away from unit.
	Safety device has cut power	Check limits. Check <a href="#">Air Flow Switch</a> (page 63).
	Dirty flame sensor	Clean flame sensor.
	Thermostat not calling for heat	Change heating set-points to call for heat.
	No spark at igniter	See <a href="#">Flame Safety Control check</a> (page 66).
	Defective valve	See <a href="#">Gas valve / Modulating gas valve check</a> (page 67).
	Loose valve wiring	See <a href="#">Gas valve / Modulating gas valve check</a> (page 67).
	Defective flame sensor	Replace flame sensor.
	Shut off valve closed	Open shut off valve.
Defective Flame Safety Controller	See <a href="#">Flame Safety Control check</a> (page 66).	
Unit cycling on high limit	Increase airflow through furnace. Check gas pressure.	
Not Enough Heat	Main gas pressure too low	Increase main gas pressure – do not exceed <b>14 in. w.c.</b> inlet pressure.
	Unit locked into low fire	<ul style="list-style-type: none"> <li>• Check wiring.</li> <li>• Check Modulating Valve settings.</li> <li>• See <a href="#">High-Fire and Low-Fire Burner Adjustment</a> (page 41)</li> </ul>
	Too much airflow	Decrease airflow if possible.
	Furnace undersized	Check design conditions.
	Gas controls not wired properly	See <a href="#">Gas valve / Modulating gas valve check</a> (page 67).
	Thermostat setting too low	Increase thermostat setting.
	Thermostat malfunction	Check thermostat.
Too Much Heat	Defective modulating gas valve	Check/replace modulating valve.
	Thermostat setting too high	Decrease thermostat setting.
	Unit locked into high fire	<ul style="list-style-type: none"> <li>• Check Modulation Valve Settings, see <b>Table 10</b>.</li> <li>• See <a href="#">High-Fire and Low-Fire Burner Adjustment</a> (page 41).</li> </ul>
	Thermostat wired incorrectly	Check thermostat wiring.
	Too much primary air	Reduce primary air.
	Manifold pressure set too high	Reduce manifold pressure.
Lifting Flames or Flashback	Dirty orifice	Check and clean orifice.
	Orifice too large	Check orifice size.
	Insufficient primary air	Increase primary air.
Yellow Tipping Flames	Misaligned orifice	Check manifold alignment.
	Insufficient primary air	Increase primary air.
	Orifice too large	Check orifice size.
Floating Flames or Flame Rollout	Manifold Pressure too high	Decrease Manifold Pressure.
	Blocked Vent	Check Venting System.
	Misaligned orifice	Check manifold alignment.

## VFD Fault List

<b>Fault Number</b>	<b>Description</b>
0	No Fault
1	IGBT Temperature Fault
2	Output Fault
3	Ground Fault
4	Temperature Fault
5	Flying Start Fault
6	High DC BUS
7	Low DC BUS
8	Overload Fault
9	OEM Fault
10	Illegal Setup Fault
11	Dynamic Brake Fault
12	Phase Lost
13	External Fault
14	Control Fault
15	Start Fault
16	Incompatible Parameter Set
17	EPM Hardware Fault
18-27	Internal Fault
28	Remote Keypad Lost
29	Assertion Level Fault
30 - 33	Internal Fault
34	Comm. Module Failure
35 - 44	Network Fault

Refer to VFD manufacturer manual for further details.

## Component Testing

### Air flow switch (PS-09)

1. Verify the vent tube is connected to the high side port for standard supply fans. When the supply fan starts, the positive pressure will close the switch and allow the supply fan to run. A fault will occur if the switch does not close.
2. If the “No Supply Air Proving” fault is active:
  - Check the rotation of the supply fan.
  - Verify the electrical connections are secure and tight. Verify vent tube is not pinched or damaged.
  - When the unit is powered ON and the supply fan is running, there should be **24V AC** at connector J13 pin 6 and J13 pin 13. If the voltage reading is incorrect at J13 pin 13, check the adjustment of the switch.

### Air Flow Switch Field Adjustment

Follow these steps if performing a part replacement, or to calibrate the switch.

- Install the switch. Install the vent tube to the correct port. Install the electrical connections.
- Power the unit ON. Monitor the HMI screen.
- Turn the adjustment screw until a fault appears on the screen, then turn the screw until the fault becomes inactive. Turn the screw two more full turns counterclockwise.

### Clogged filter switch (PS-10)

1. The vent tube should be connected to the low side port. A fault will occur when the switch senses a negative pressure.
2. If the “Clogged Filters” fault is active:
  - Check the filters. If the filters are clogged or damaged, replace as needed. Check for any other obstructions in the unit.
  - Verify the electrical connections are secure and tight. Verify vent tube is not pinched or damaged.
  - When the unit is powered ON, there should be **24V AC** at connector J13 pin 5 and **0V AC** J13 pin 12. If there is voltage at pin 12, check the adjustment of the switch.

### Clogged Filter Switch Field Adjustment

Follow these steps if performing a part replacement, or to calibrate the switch.

1. Install the switch. Install the vent tube on the low side port. Install the electrical connections.
2. Use material suitable to block the filter. This will create a clogged filter symptom.
3. Power the unit ON. The switch should now be closed, and the ‘Clogged Filters’ fault should be active. Check for voltage at the following pins:
  - Common pin to ground. There should be **24-28V AC**.
  - Normally open pin to ground. There should be **24-28V AC**.
- A. If the voltage reading is correct, remove the material blocking the filter. The fault should clear. If the fault is present, adjust the switch until set properly.
- B. If the voltage reading is incorrect, adjust the switch until the proper voltage is obtained at the pins. Block the filter, and monitor that the switch closes (clogged). Unblock the filter, and monitor that the switch opens (unclogged).

Figure 42 - Air Flow Switch and Wiring Reference





Figure 43 - Clogged Filter Switch and Wiring Reference



## Intake (SN-03)/Return (SN-04)/Outdoor (SN-05)/Discharge (SN-06) Temperature sensor

1. Make sure the unit is OFF.
2. Make sure the wires are connected properly.
3. Measure the resistance of the temperature sensor at the IBT board connector J15.
  - SN-03 – pin 1 to pin 2
  - SN-04 – pin 3 to pin 4
  - SN-05 – pin 5 to pin 6
  - SN-06 – pin 7 to pin 8

Use the temperature/ohm chart to determine your readings.

- A. If there is **0 ohms** the sensor or wires are shorted.
- B. If there is **infinite (OL) ohms** the sensor or wires are open.

If the sensor or wiring has failed, replace the sensor.

Figure 44 – Wiring Reference





Table 15 - Sensor Ohm Reading

Temperature	Ohm 10k
-20	165k
-10	117k
0	85k
10	62k
20	46k
30	34k
40	26k
50	19k
60	15k
70	11k
80	9k
90	7k
100	5k

## Vent Proving switch (PS-01)

1. Make sure the wiring is connected properly.
2. Verify the vent tubing is routed correctly, and the tube is not pinched or clogged.
3. Make sure the unit is OFF. Check the switch. Remove the electrical connections. Check for continuity between pins:
  - Pin "C" to pin "NO". There should be no continuity.
    - If there is continuity, the switch has failed. Replace the switch.
    - If there is no continuity, re-connect the electrical connections. Continue to the next step.
4. Connect a manometer between the pressure switch, and hose. Power the unit ON, and monitor the manometer. Verify the value (**w.c.**) on the switch is correct.
  - If the reading is below the set point, there is an issue with the vacuum.
  - If the reading is above the set point, continue to the next step.
5. With the unit ON. Check for voltage:
  - Back probe connector J7-pin 14 to ground. There should be **24-28V AC**.
  - Back probe connector J7-pin 10 to ground. There should be **24-28V AC**.
    - If the voltage reading is incorrect, check the wiring for an open or short circuit. If the wiring check is good, the switch has failed. Replace the switch.
    - If the voltage reading is correct, there may have been an intermittent fault.

Figure 45 - Vent Proving Switch and Wiring Reference




### Low Gas Pressure switch (PS-05)

- Power the unit ON. Verify the inlet pressure gauge is reading the correct pressure.
  - Natural gas - **7 in. w.c. – 14 in. w.c.**
  - Propane - **11 in. w.c. – 14 in. w.c.**

**Note: If the reading is incorrect, contact the gas supply company.**
- Reset the lever on the switch. Gas pressure must be higher in the chamber for the reset latch to be set properly.
  - If the reset did not work, continue with the next step.
- Remove the cover. Make sure the wiring is set up for Normally Open (N.O.) contact.
- Check for voltage:
  - Back probe connector J13-pin 3 to ground. There should be **24-28V AC**.
  - Back probe connector J13-pin 10 to ground. There should be **0V AC**.
    - If the voltage reading is incorrect, check the wiring for an open or short circuit. If the wiring is correct, the switch has failed. Replace the switch
    - If the voltage reading is correct, and the switch reset corrected the fault, there may have been an intermittent fault.


**Figure 46 - Low Gas Pressure and Wiring Reference**



### High Gas Pressure switch (PS-07) (PS-08)

- Power the unit ON. Reset the lever on the switch. Gas pressure must be lower in the chamber for the reset latch to be set properly.
- Remove the cover. Make sure the wiring is set up for Normally Closed (N.C.) contact.
- Verify the On/Off gas valve, and modulating valve are set properly. See [High-Fire and Low-Fire Burner Adjustment](#) (page 41)
- Check for voltage:
  - Back probe connector J13-pin 3 to ground. There should be **24-28V AC**.
  - Back probe connector J13-pin 10 to ground. There should be **24-28V AC**.
    - If the voltage reading is incorrect, check the wiring for an open or short circuit. If the wiring is correct, the switch has failed. Replace the switch
    - If the voltage reading is correct, and the switch reset corrected the fault, there may have been an intermittent fault.

**Figure 47 - High Gas Pressure and Wiring Reference**



### Flame Safety Control (FSC-01)

1. Make sure the wiring is connected properly.
2. Power the unit ON. Use the HMI to set the unit in test mode.
  - Service > Test Menu > Test Heating > Run Low Fire Test > Stages All
  - Refer to the operation of sequence, [Flame Safety Control](#) (page 49).

Determine the symptom below:

Symptom	Action
Control does not start	-Check wiring -Check for a <b>24V AC</b> transformer failure -Check circuit breaker -Check LED light
Thermostat ON – no spark	-Check wiring to thermostat input (TH) -Faulty thermostat -Check LED light
Blower ON – no Trial For Ignition (TFI) after purge delay	-Check wiring -Check for flame fault -Air Flow fault, see <a href="#">Air Flow Switch</a> (page 63). -Check connection at PSW terminal -Faulty Control (Check voltage between L1 and IND. There should be <b>24V AC</b> )
Valve ON – no spark during TFI	-Check wiring -Shorted ignitor electrode -Check cable to ignitor
Spark ON – valve OFF	-Check wiring -Valve coil open -Check voltage at V1
Flame during TFI – no flame sensed after TFI	-Check flame rod position -Check cable to flame rod -Poor ground connection at burner -Poor flame


3. Power the unit ON. If the LED is blinking, verify the fault:
  - Steady ON = Internal controller failure
  - 1 flash = Airflow fault
  - 2 flashes = Flame without call for heat
  - 3 flashes = Ignition lock out

### Modulating Gas Valve (VA-05) (VA-06)

- Make sure the wiring is connected properly. Check the wiring using a multi-meter for open or short circuits.
  - Terminal 1 – Signal (+) to J7-pin 6/J8-pin 6
  - Terminal 2 – Signal (-) to J7-pin 7/J8-pin 7
  - Terminal 3 – Power **24V DC (+)** to H
  - Terminal 4 – Power (-) to N
    - If any damaged wiring is found, repair or replace.
    - If any open or short circuits are found, repair or replace.
    - If any wiring is connected incorrectly, correct the wiring.

**Note: The wiring connection is polarity sensitive.**
- Make sure the DIP switches are all in the OFF position (factory setting). This will set the valve to receive a **0-10V DC** signal. If the unit is set up for an analog control system, see **Table 10**.
- Make sure the valve has been adjusted properly. See [High-fire and Low-fire burner adjustment](#) (page 41).
- If the unit has been running, restart the unit. Check for voltage:
  - Connector J7-pin 6/J8-pin 6 to ground. There should be **10V DC**. The voltage reading will drop after the unit has been running.
  - Check for voltage between H to N on the terminal block. There should be **24-28V AC**. This voltage reading will be constant.
    - If the voltage reading is incorrect, check voltage to the IBT control board.
    - If the voltage reading is correct, there may be an issue with the modulating valve.


**Figure 48 - Modulating Gas Valve and Wiring Reference**



### Main (ON/OFF) Gas Valve (VA-01)

- Make sure the wiring is connected properly.
- Make sure the gas valve is ON.
- Power the unit ON. Check for voltage. Check for voltage across the pins on the gas valve. There should be **24-28V AC**.
  - If the voltage reading is incorrect, check the wiring for an open or short circuit.
  - If the voltage reading is correct, the gas valve may be faulty.

**Figure 49 - Main Gas Valve and Wiring Reference**



# MAINTENANCE

To guarantee trouble free operation of this heater, the manufacturer suggests following these guidelines. Most problems associated with fan failures are directly related to poor service and maintenance.

Please record any maintenance or service performed on this fan in the documentation section located at the end of this manual.

**WARNING: DO NOT ATTEMPT MAINTENANCE ON THE HEATER UNTIL THE ELECTRICAL SUPPLY HAS BEEN COMPLETELY DISCONNECTED AND THE MAIN GAS SUPPLY VALVE HAS BEEN TURNED OFF.**

## General Maintenance

1. Fan inlet and approaches to ventilator should be kept clean and free from any obstruction.
2. Motors are normally permanently lubricated. Check bearings periodically. If they have grease fittings lubricate each season. Use caution when lubricating bearings, wipe the fittings clean, the unit should be rotated by hand while lubricating. **Caution: Use care when touching the exterior of an operating motor. Motors normally run hot and may be hot enough to be painful or cause injury.**
3. All fasteners should be checked for tightness each time maintenance checks are performed prior to restarting unit.
4. Blowers require very little attention when moving clean air. Occasionally oil and dust may accumulate causing imbalance. If the fan is installed in a corrosive or dirty atmosphere, periodically inspect and clean the wheel, inlet and other moving parts to ensure smooth and safe operation.
5. Before each heating season, verify that the drain on the bottom of each common flue box of every furnace in the unit is clear.

## Re-Setting of the Unit

If the flame safety control is locked out (Spark igniter fails or no gas supply), reset the unit by:

1. Turn OFF Power to the unit.
2. Turn Power to the unit back ON.

## Emergency shutdown of unit

To shut down the unit in the event of an emergency do the following:

1. Turn power OFF to the unit from main building disconnect.
2. Turn the external disconnect switch to the OFF position.
3. CLOSE the inlet gas valve located on the heater.

## Prolonged shutdown of the unit

For prolonged shutdown the following steps should be done:

1. Turn the external disconnect switch to the OFF position.
2. CLOSE the inlet gas valve located on the heater.

To re-start the unit the following steps should be done:

1. Turn the external disconnect switch to the ON position.
2. OPEN the inlet gas valve located on the heater.

## 2 weeks after startup

1. Belt tension should be checked after the first 2 weeks of fan operation. Belts tend to stretch and settle into pulleys after an initial start-up sequence. **Do not tension belts by changing the setting of the motor pulley**, this will change the fan speed and may damage the motor. To re-tension belts, turn the power to the fan motor OFF. Loosen the fasteners that hold the blower scroll plate to the blower. Rotate the motor to the left or right to adjust the belt tension. Belt tension should be adjusted to allow 1/64" of deflection per inch of belt span. Exercise extreme care when adjusting V-belts as not to misalign pulleys. Any misalignment will cause a sharp reduction in belt life and produce squeaky noises. Over-tightening will cause excessive belt and bearing wear as well as noise. Too little tension will cause slippage at startup and uneven wear. **Whenever belts are removed or installed, never force belts over pulleys without loosening motor first to relieve belt tension.** When replacing belts, use the same type as supplied by the manufacturer. On units shipped with double groove pulleys, matched belts should always be used.
2. All fasteners should be checked for tightness each time maintenance checks are performed prior to restarting unit.

## Every 3 months

1. Belt tension should be checked quarterly. See instructions in the previous maintenance section. Over-tightening will cause excessive bearing wear and noise. Too little tension will cause slippage at startup and uneven wear.
2. Filters need to be cleaned and/or replaced quarterly, and more often in severe conditions. Washable filters can be washed in warm soapy water. When re-installing filters, be sure to install with the **airflow in the correct direction** as indicated on the filter.

**Table 16 - Filter Quantity Chart**

Intake	16" x 20"	20" x 25"
Size 1 Sloped	3	
Size 2 Sloped		3
Size 3 Sloped	6	
Size 4 Sloped	10	
Size 5 Sloped		8
Size 1 V-Bank		3
Size 2 V-Bank	8	
Size 3 V-Bank		8
Size 4 V-Bank	15	
Size 5 V-Bank		12

**Table 17 - Optional Mixing Box Filters**

Diagonal Filters			Vertical Filters		
Unit Size	Filter Quantity	Filter Size	Unit Size	Filter Quantity	Filter Size
1	4	10 x 16	1	1	10 x 16
2	2	20 x 25	2	1	16 x 25
3	4	15 x 20	3	2	15 x 15
4	4	18 x 25	4	2	16 x 20
5	9	14.5 x 19	5	3	14.5 x 19

## Yearly


1. Before each heating season, verify that the drain on the bottom of each common flue box of every furnace in the unit is clear.
2. Inspect bearings for wear and deterioration. Replace if necessary.
3. Inspect belt wear and replace torn or worn belts.
4. Inspect bolts and set screws for tightness. Tighten as necessary.
5. Inspect motor for cleanliness. Clean exterior surfaces only. Remove dust and grease from the motor housing to ensure proper motor cooling. Remove dirt and grease from the wheel and housing to prevent imbalance and damage.
6. The heat exchanger should be checked for cracks. The heat exchanger should be replaced immediately if cracks are detected.
7. Inspect the combustion blower motor for cleanliness. Clean exterior surfaces of the combustion blower motor only. Removing excess dust and grease guarantees proper motor cooling.
8. Before each heating season, examine the burner and gas orifices. Inspect burner ports for foreign debris, heat exchanger, and spark igniter for cleanliness.

## Heat Exchanger Inspection

**NOTE: Below is for size 1 and 2 units.**

1. To inspect the heat exchanger, remove the access door on backside side of unit.
2. Visually inspect the heat exchanger. Check for splits, cracks or holes in the tubes and joints. If damage is found, replace the heat exchanger.


**Figure 50 – Size 1 and Size 2 Heat Exchanger**






**NOTE: Below is for size 3-5 units.**

1. To inspect the heat exchanger, remove the access door on backside side of unit. This will expose the insulated heat exchanger compartment.
2. Use a sharp razor knife to cut the reinforced silver tape around all four outer edges, and down the center of the two halves.
3. Remove the insulation. Silicone is used to adhere the insulation to the panel.
4. Remove the screws from the right side panel first. Then remove the screws from the left panel. Remove both panels to expose the heat exchanger.
5. Visually inspect the heat exchanger. Check for splits, cracks or holes in the tubes and joints. If damage is found, replace the heat exchanger.





**Figure 51 – Size 2 to Size 5 Heat Exchanger**









# Appendix A – IBT Board Electrical Connections

<p>RJ45 Connectors</p>	
<p>J1 Auxiliary slave port J2 Programming port (service only) J3 connects to HMI J4 connects to VFD controller</p>	<p>J5 connects to Cat 5 converter for Compressor Frequency Drive J6 connects to electronic expansion controller</p>
<p>J7 (FSC-1) and J8 (FSC-2) connectors contain inputs and outputs for Flame Safety Controller (FSC), furnace, and gas train. J7 comes standard as stage 1 furnace, J8 as stage 2 furnace.</p>	
<p>Pin 1 - <b>24V AC</b> output to Pressure Switch input (PSW) on FSC Pin 2 - <b>24V AC</b> output to Thermostat input (TH/W) on FSC Pin 3 - detects <b>24V AC</b> presence from IND on FSC Pin 4 - <b>24V AC</b> output to valve power (V1) on FSC Pin 5 - <b>24V AC</b> output to main gas valve Pin 6 - <b>0-10V DC (+)</b> to modulating gas valve or Electric Heater (option) Pin 7 - <b>0-10V DC (-)</b> to modulating gas valve Pin 8 - modulating gas valve shield</p>	<p>Pin 9 - ground to main gas valve Pin 10 - detects <b>24V AC</b> presence from vent proving switch Pin 11 - <b>24V AC</b> output (L1) on FSC Pin 12 - <b>24V AC</b> supply power (R) on FSC Pin 13 - <b>24V AC</b> out to high limit switch Pin 14 - <b>24V AC</b> out to vent proving switch Pin 15 - detects <b>24V AC</b> presence from roll out switch Pin 16 - detects <b>24V AC</b> presence from high limit switch Pin 17 - <b>24V AC</b> out to roll out switch Pin 18 - valve ground (V2) on FSC</p>
<p>Connector J9 contains <b>120V AC</b> connections</p>	
<p>Pin 1 - <b>120V AC</b> input Pin 2 - tied to Pin 1 internally to the board Pin 3 - detects <b>120V AC</b> presence for fire condition Pin 4 - <b>120V AC</b> out to damper</p>	<p>Pin 5 - <b>120V AC</b> presence from damper end limit Pin 6 - <b>120V AC</b> out to drain heater Pin 7 - <b>120V AC</b> out to cabinet heater Pin 8 - <b>120V AC</b> neutral</p>



<p>Connector J14 contains screw terminal connections for relative humidity sensors</p>	
<p>Pin 1 - <b>24V DC (+)</b> to humidity sensor  Pin 2 - <b>0-10V DC</b> input from humidity sensor  Pin 3 - <b>0-10V DC</b> common from humidity sensor  Pin 4 - <b>24V DC</b> common to humidity sensor</p>	<p>Pin 5 - <b>24V DC +</b> to humidity sensor  Pin 6 - <b>0-10V DC</b> input from humidity sensor  Pin 7 - <b>0-10V DC</b> common from humidity sensor  Pin 8 - <b>24V DC</b> common to humidity sensor</p>
<p>Connector J15 contains screw terminal connections for 10k temperature thermistors only</p>	
<p>Pins 1 and 2 - for intake sensor  Pins 3 and 4 - for return sensor  Pins 5 and 6 - for outdoor sensor</p>	<p>Pins 7 and 8 - for discharge sensor  Pins 9 and 10 - for space temperature sensor</p>
<p>Connector J16 contains low voltage screw terminal connections for BAS/DDC/Space</p>	
<p>Pin 1 - Analog Control /DDC <b>0-10V DC</b> input  Pin 2 - Analog Control /DDC <b>4-20mA</b> input  Pin 3 - Analog Control /DDC analog input common  Pin 4 - Analog Control /DDC shield</p>	<p>Pin 5 - aux in for unit interlock  Pin 6 - <b>24V AC</b> out  Pin 7 - <b>24V AC</b> out  Pin 8 - common</p>
<p>Connector J17 triac output for power vent 2</p>	

Connector J18 contains low voltage connections	
Pin 1 - <b>24V DC (+)</b> spare output Pin 2 - <b>0-10V DC (+)</b> for modulating damper Pin 3 - <b>0-10V DC (+)</b> spare Pin 4 - dx float switch output Pin 5 - <b>24V AC</b> out spare unit interlock Pin 6 - unused connection Pin 7 - unused connection	Pin 8 - <b>24V DC (-)</b> spare output Pin 9 - <b>0-10V DC (-)</b> for modulating damper Pin 10 - <b>0-10V DC (-)</b> spare Pin 11 - dx float switch common Pin 12 - <b>24V AC</b> common spare unit interlock Pin 13 - unused connection Pin 14 - unused connection
Connector J19 triac output for second power vent 2	
Connector J20 triac neutral for second power vent	
Connector J21 triac neutral for first power vent	
Connector J22 (Y1) contains 24V AC condenser 1 outputs	
Pin 1 - <b>24V AC out</b>	Pin 2 - <b>24V AC</b> common
Connector J23 (Y2) contains <b>24V AC</b> condenser 2 outputs Connector J24 (Y3) contains <b>24V AC</b> condenser 3 outputs	
Pin 1 - <b>24V AC out</b>	Pin 2 - <b>24V AC</b> common
Connector J25 factory programming only, Zilog ZDI microcontroller debug/programming interface	
Pin 1 - <b>3.3V DC</b> Pin 2 - reset Pin 3 - Gnd	Pin 4 - DBG input Pin 5 - Gnd Pin 6 - NC

# Appendix B – IBT DDC Points

## Full External Control Points:

BACNET OBJECT NAME	BACNET OBJECT ID	BACNET DATA TYPE	LON SNVT NAME	SNVT TYPE	FUNCTION	DEFAULT	RANGE	DESCRIPTION
HeatCommand	1	Binary Value	nviHeatCommand	SNVT_count	Control	0	0-1	OFF(0) / ON(1)
CoolCommand	2	Binary Value	nviCoolCommand	SNVT_count	Control	0	0-1	OFF(0) / ON(1)
FanCommand	3	Binary Value	nviFanCommand	SNVT_count	Control	0	0-1	OFF(0) / ON(1)

- Use only if Heating and/or Cooling tempering mode has been set to “DDC” through the unit’s HMI.
- Setting the Heating and Cooling modes to “DDC” **disables temperature based activation of these functions**. The preferred heating and cooling activation method is to use space and/or intake temperatures along with unit set points.
- Heating and Cooling cannot be called for at the same time.
- The Fan Control point will only work if the heating or cooling mode is set to DDC.

For factory settings and temperature set points BACNET and LON points are displayed on to the BMS as raw values. The BMS must scale these points when reading and/or writing based on the point description. For example, temperature sensor values must be divided by 10 after they are read. Likewise, when writing to a set point, the intended value must be multiplied by 10 before being sent to the controller.

## Factory Settings:

BACNET OBJECT NAME	BACNET OBJECT ID	BACNET DATA TYPE	LON SNVT NAME	SNVT TYPE	FUNCTION	DEFAULT	RANGE	DESCRIPTION
NumberOfHMIs	4	Analog Value	nviNumberOfHMIs	SNVT_count	Monitor/Control	1	1-5	HMI1 is always the cabinet HMI
IncludeHMIAvg	5	Analog Value	nviIncludeHMIAvg	SNVT_count	Monitor/Control	2	1-31 odd	Bitfield, if bit=1 that HMI is read only
SetHeatStages	6	Analog Value	nviSetHeatStages	SNVT_count	Monitor/Control	0	0-4	One IBT Board can support 2 stages
SetCondenserStages	7	Analog Value	nviSetCondStages	SNVT_count	Monitor/Control	0	0-5	Distinction between the number of condensers and the number of condenser cooling stages
FreezestatTime	8	Analog Value	nviFstatTime	SNVT_count	Monitor/Control	10	1-10	Time in Minutes
EvapSprayONTime	9	Analog Value	nviEvSprayONt	SNVT_count	Monitor/Control	Set By Plant	0-60	Time in Seconds
EvapSprayOFFTime	10	Analog Value	nviEvSprayOFFt	SNVT_count	Monitor/Control	Set By Plant	0-500	Time in Seconds
MinVFDFreqOccupied	11	Analog Value	nviMinVFDFreqO	SNVT_count	Monitor/Control	0	0-MaxVFDFreq	Freq(Hz)*10
MaxVFDFreqOccupied	12	Analog Value	nviMaxVFDFreqO	SNVT_count	Monitor/Control	80	MinVFDFreq-800	Freq(Hz)*10
MinOAPercentOccupied	13	Analog Value	nviMinOAPercentO	SNVT_count	Monitor/Control	0	0-Max Outdoor Air %	Minimum Percentage of Outdoor Air
MaxOAPercentOccupied	14	Analog Value	nviMaxOAPercentO	SNVT_count	Monitor/Control	100	Min Outdoor Air %-100	Maximum Percentage of Outdoor Air
MinPWMOccupied	15	Analog Value	nviMinPWMO	SNVT_count	Monitor/Control	0	0-Max PWM	ECM Minimum Speed
MaxPWMOccupied	16	Analog Value	nviMaxPWMO	SNVT_count	Monitor/Control	100	Min PWM-100	ECM Maximum Speed
SchedulingEnable	17	Binary Value	nviSchedEnable	SNVT_count	Monitor/Control	0	0-1	Disabled (0) / Enabled (1)
CoolDXLowTempLimit	18	Analog Value	nviCoolDXLowTLim	SNVT_count	Monitor/Control	55°F 13°C	400-700°F 40-210°C	Temperature*10
EvapDrainValveSP	19	Analog Value	nviEvapDValveSP	SNVT_count	Monitor/Control	400°F 40°C	350-1100°F 20-100°C	Temperature*10
EvapDrainValveSPDiff	20	Analog Value	nviEvapDValveSPDif	SNVT_count	Monitor/Control	20°F 20°C	10-50°F 10-30°C	Temperature*10
EvapCoolingDiff	21	Analog Value	nviEvapCoolDif	SNVT_count	Monitor/Control	30°F 20°C	10-100°F 10-60°C	Temperature*10
MinOAPercentUnoccupied	22	Analog Value	nviMinOAPercentU	SNVT_count	Monitor/Control	0%	0-Max %	Percentage of outdoor air
MaxOAPercentUnoccupied	23	Analog Value	nviMaxOAPercentU	SNVT_count	Monitor/Control	100%	Min-100%	Percentage of outdoor air
MinVFDFreqUnoccupied	24	Analog Value	nviMinVFDFreqU	SNVT_count	Monitor/Control	30Hz	0-VFD Max	Freq (Hz) *10
MaxVFDFreqUnoccupied	25	Analog Value	nviMaxVFDFreqU	SNVT_count	Monitor/Control	60Hz	VFD Min-800	Freq (Hz) *10
MinPWMUnoccupied	26	Analog Value	nviMinPWMU	SNVT_count	Monitor/Control	0%	0-Max PWM	Motor speed %
MaxPWMUnoccupied	27	Analog Value	nviMaxPWMU	SNVT_count	Monitor/Control	100%	Min PWM - 100	Motor speed %
CoolEvapLowTempLimit	28	Analog Value	nviCoolELowTLim	SNVT_count	Monitor/Control	800°F 38°C	60-100°F 16-38°C	Temperature*10

- Writing to any of these registers will trigger a system reboot. Avoid writing to these on a regular basis.
- The Scheduling Enable point tells the unit whether scheduling is allowed or not. It is **NOT** an occupancy command.

### Temperature Set Points:

BACNET OBJECT NAME	BACNET OBJECT ID	BACNET DATA TYPE	LON SNVT NAME	SNVT TYPE	FUNCTION	DEFAULT	RANGE	DESCRIPTION
InHeatOccSP	29	Analog Value	nviInHeatOccSP	SNVT_count	Monitor/Control	450°F 70°C	350-1100°F 20-430°C Intake Heat SP + Intake Heat Diff < Intake Cool SP	Temperature*10
SpaceHeatOccSP	30	Analog Value	nviSpaceHOccSP	SNVT_count	Monitor/Control	700°F 210°C	350-1100°F 20-430°C Space Heat SP + Space Heat Diff < Space Cool SP	Temperature*10
MinDischHeatSP	31	Analog Value	nviMinDischHSP	SNVT_count	Monitor/Control	600°F 160°C	400°F-DischHeatOccSP 40°C-DischHeatOccSP	Temperature*10
DischHeatOccSP	32	Analog Value	nviDischHOccSP	SNVT_count	Monitor/Control	600°F 160°C	MinDischHeatSP- MaxDischHeatOccSP	Temperature*10
MaxDischHeatOccSP	33	Analog Value	nviMaxDischHOccSP	SNVT_count	Monitor/Control	1200°F 490°C	DischHeatOccSP-1500°F DischHeatOccSP-660°C	Temperature*10
InCool1OccSP	34	Analog Value	nviInCool1OccSP	SNVT_count	Monitor/Control	850°F 290°C	550-1000°F 130-380°C Intake Cool SP - Intake Cool Hyst > Intake Heat SP	Temperature*10
IntakeCoolOccStageDiff	35	Analog Value	nviInCOccStgDif	SNVT_count	Monitor/Control	100°F 60°C	0-200°F 0-110°C	Temperature*10
SpaceCoolOccStageDiff	36	Analog Value	nviSpCOccStgDif	SNVT_count	Monitor/Control	30°F 20°C	0-200°F 0-110°C	Temperature*10
SpaceCoolOccSP	37	Analog Value	nviSpaceCOccSP	SNVT_count	Monitor/Control	740°F 230°C	500-900°F 100-320°C Space Cool SP - Space Cool Hyst > Space Heat SP	Temperature*10
EvapCoolOccSP	38	Analog Value	nviEvapCoolOccSP	SNVT_count	Monitor/Control	850°F 290°C	550-1000°F 130-380°C	Temperature*10
InHeatUnoccSP	39	Analog Value	nviInHeatUnoccSP	SNVT_count	Monitor/Control	450°F 70°C	350-1100°F 20-430°C	Temperature*10
SpaceHeatUnoccSP	40	Analog Value	nviSpaceHUoccSP	SNVT_count	Monitor/Control	700°F 210°C	350-1100°F 20-430°C	Temperature*10
MinDischHeatUnoccSP	41	Analog Value	nviMinDisHUoccSP	SNVT_count	Monitor/Control	600°F 160°C	400°F-DischHeatUnoccSP 40°C-DischHeatUnoccSP	Temperature*10
DischHeatUnoccSP	42	Analog Value	nviDischHUoccSP	SNVT_count	Monitor/Control	600°F 160°C	MinDischHeatUnoccSP- MaxDischHeatUnoccSP	Temperature*10
MaxDischHeatUnoccSP	43	Analog Value	nviMaxDisHUoccSP	SNVT_count	Monitor/Control	1200°F 490°C	DischHeatUnoccSP-1500°F DischHeatUnoccSP-660°C	Temperature*10
InCool1UnoccSP	44	Analog Value	nviInC1UnoccSP	SNVT_count	Monitor/Control	850°F 290°C	550-1000°F 130-380°C	Temperature*10
IntakeCoolUnoccStageDiff	45	Analog Value	nviInCUnocStgDif	SNVT_count	Monitor/Control	100°F 60°C	0-200°F 0-110°C	Temperature*10
SpaceCoolUnoccStageDiff	46	Analog Value	nviSpCUnocStgDif	SNVT_count	Monitor/Control	30°F 20°C	0-200°F 0-110°C	Temperature*10
SpaceCoolUnoccSP	47	Analog Value	nviSpaceCUnoccSP	SNVT_count	Monitor/Control	740°F 230°C	500-900°F 100-320°C	Temperature*10
EvapCoolUnoccSP	48	Analog Value	nviEvapCUnoccSP	SNVT_count	Monitor/Control	850°F 290°C	550-1000°F 130-380°C	Temperature*10
InFirestatSP	49	Analog Value	nviInFirestatSP	SNVT_count	Monitor/Control	1350°F 570°C	1000-3000°F 380-1490°C	Temperature*10
DischFirestatSP	50	Analog Value	nviDischFstatSP	SNVT_count	Monitor/Control	2400°F 1160°C	1000-3000°F 380-1490°C	Temperature*10
CabinetHeatSP	51	Analog Value	nviCabinetHeatSP	SNVT_count	Monitor/Control	0°F -180°C	0-400°F (-180)-40°C	Temperature*10
FreezestatSP	52	Analog Value	nviFreezestatSP	SNVT_count	Monitor/Control	350°F 20°C	(-400)-750°F (-400)-24°C	Temperature*10
FurnaceDrainHeatSP	53	Analog Value	nviFurnDrainHSP	SNVT_count	Monitor/Control	350°F 20°C	350-450°F 20-70°C	Temperature*10
RoomOverrideSP	54	Analog Value	nviRoomOrideSP	SNVT_count	Monitor/Control	900°F 310°C	600-1200°F 160-490°C	Temperature*10

- The preferred method for DDC control is through set point manipulation. Use the set points shown above along with the “DDC Occupied Override” point in the Runtime settings section to control the blower and to determine when to heat or cool.
- Temperatures can be in degrees F or degrees C, depending on the “Temp Units” point in the factory settings.

### Runtime Settings and Indicators:

BACNET OBJECT NAME	BACNET OBJECT ID	BACNET DATA TYPE	LON SNVT NAME	SNVT TYPE	FUNCTION	DEFAULT	RANGE	DESCRIPTION
VFDFrequencySettingOcc	55	Analog Value	nviVFDFrequencyO	SNVT_count	Monitor/Control	Set By Plant	VFD Min Freq-VFD Max Freq	Running VFD Frequency
PWMRateOccupied	56	Analog Value	nviPWMRateO	SNVT_count	Monitor/Control	Set By Plant	Min PWM-Max PWM	Running PWM Rate
MixBoxUnoccOAPercent	57	Analog Value	nviMBoxUnocOAPer	SNVT_count	Monitor/Control	0	Min Outdoor Air %-Max Outdoor Air %	Percentage of Outdoor Air Unoccupied
MixBoxOccOAPercent	58	Analog Value	nviMBoxOcOAPer	SNVT_count	Monitor/Control	100	Min Outdoor Air %-Max Outdoor Air %	Percentage of Outdoor Air Occupied
MixingDamperVolts	59	Analog Value	nviMDamperV	SNVT_count	Monitor/Control	0	0-1000	Volts*100
DDCOccupiedOverride	60	Binary Value	nviDDCOccupOride	SNVT_count	Monitor/Control	0	0-1	Override Off(0) – Override On(1)
FSC1GasON	61	Binary Input	nvoFSC1GasON	SNVT_count	Monitor	0	0-1	Off(0) – On(1)
FSC2GasON	62	Binary Input	nvoFSC2GasON	SNVT_count	Monitor	0	0-1	Off(0) – On(1)
FSC3GasON	63	Binary Input	nvoFSC3GasON	SNVT_count	Monitor	0	0-1	Off(0) – On(1)
FSC4GasON	64	Binary Input	nvoFSC4GasON	SNVT_count	Monitor	0	0-1	Off(0) – On(1)
VFDFrequencySettingUnoccupied	65	Analog Value	nviVFDFreqU	SNVT_count	Monitor/Control	Set By Plant	VFD Min Freq-VFD Max Freq	Unoccupied Running
PWMRateUnoccupied	66	Analog Value	nviPWMRateU	SNVT_count	Monitor/Control	Set By Plant	Min PWM-Max PWM	Unoccupied Running
CoolingOutputY1	67	Binary Input	nvoCoolOutY1	SNVT_count	Monitor	0	0-1	Off(0) – On(1)
CoolingOutputY2	68	Binary Input	nvoCoolOutY2	SNVT_count	Monitor	0	0-1	Off(0) – On(1)
CoolingOutputY3	69	Binary Input	nvoCoolOutY3	SNVT_count	Monitor	0	0-1	Off(0) – On(1)
AirQuality	70	Analog Value	nvoAirQuality	SNVT_count	Monitor	0	0-1000	Volts*100
AnalogHeatControl 0-10V	71	Analog Value	nviAVHeat0-10V	SNVT_count	Monitor/Control	0	0-1000	Volts*100

- Use the “DDC Occupied Override” point to switch between occupied and unoccupied settings and set points. **Make sure that all timeslots in the unit’s internal schedule are set to “Unoccupied” in order to avoid conflicting commands. This can be verified through the unit’s HMI.**
- To control the blower through the “DDC Occupied Override” point, set the blower mode to “ON/AUTO/OFF” during occupied and unoccupied times, depending on the required sequence of operations.
- FSC1-4 points can be used as indicators that the unit is attempting to heat. Cooling Outputs Y1-3 points can be used as indicators that the unit is attempting to cool.
- Analog heat control can only be used if the heating tempering mode is set to “DDC”.

### Sensor Values and Alerts:

BACNET OBJECT NAME	BACNET OBJECT ID	BACNET DATA TYPE	LON SNVT NAME	SNVT TYPE	FUNCTION	DEFAULT	RANGE	DESCRIPTION
DamperPositionReference	72	Analog Input	nvoDamperPos	SNVT_count	Monitor	-	0-1000	Volts*100
SupplySpeedReference	73	Analog Input	nvoSupSpeedRef	SNVT_count	Monitor	-	0-1000	Volts*100
OATemp	74	Analog Input	nvoOATemp	SNVT_count	Monitor	-	(-64)-302°F (-53)-150°C	Temperature*10
ReturnTemp	75	Analog Input	nvoReturnTemp	SNVT_count	Monitor	-	(-64)-302°F (-53)-150°C	<Min = Disconnected >Max = Broken
DischargeTemp	76	Analog Input	nvoDischargeTemp	SNVT_count	Monitor	-	(-64)-302°F (-53)-150°C	<Min = Disconnected >Max = Broken
IntakeTemp	77	Analog Input	nvoIntakeTemp	SNVT_count	Monitor	-	(-64)-302°F (-53)-150°C	<Min = Disconnected >Max = Broken
SpaceTemp	78	Analog Input	nvoSpaceTemp	SNVT_count	Monitor	-	(-64)-302°F (-53)-150°C	<Min = Disconnected >Max = Broken
RTCTemp	79	Analog Input	nvoRTCTemp	SNVT_count	Monitor	-	(-40)-185°F (-40)-85°C	<Min = Disconnected >Max = Broken
HMI1Temp	80	Analog Input	nvoHMI1Temp	SNVT_count	Monitor	-	(-40)-257°F (-40)-125°C	<Min = Disconnected >Max = Broken
HMI2Temp	81	Analog Input	nvoHMI2Temp	SNVT_count	Monitor	-	(-40)-257°F (-40)-125°C	<Min = Disconnected >Max = Broken
HMI3Temp	82	Analog Input	nvoHMI3Temp	SNVT_count	Monitor	-	(-40)-257°F (-40)-125°C	<Min = Disconnected >Max = Broken
HMI4Temp	83	Analog Input	nvoHMI4Temp	SNVT_count	Monitor	-	(-40)-257°F (-40)-125°C	<Min = Disconnected >Max = Broken
HMI5Temp	84	Analog Input	nvoHMI5Temp	SNVT_count	Monitor	-	(-40)-257°F (-40)-125°C	<Min = Disconnected >Max = Broken
AlertCode1	85	Analog Input	nvoAlertCode1	SNVT_count	Monitor	-	0-87	See fault code table page 80
AlertCode2	86	Analog Input	nvoAlertCode2	SNVT_count	Monitor	-	0-87	See fault code table page 80
AlertCode3	87	Analog Input	nvoAlertCode3	SNVT_count	Monitor	-	0-87	See fault code table page 80
AlertCode4	88	Analog Input	nvoAlertCode4	SNVT_count	Monitor	-	0-87	See fault code table page 80
AlertCode5	89	Analog Input	nvoAlertCode5	SNVT_count	Monitor	-	0-87	See fault code table page 80
AlertCode6	90	Analog Input	nvoAlertCode6	SNVT_count	Monitor	-	0-87	See fault code table page 80
UnitStatus	91	Analog Input	nvoUnitStatus	SNVT_count	Monitor	-	0-3	0= Idle 1= Heating 2= Cooling 3 = Blower Only

- Temperatures can be in degrees F or degrees C, depending on the “Temp Units” point in the factory settings.
- Values should be scaled by the Building Management System (see point description).

### Variable Frequency Drive Information (Read-Only):

BACNET OBJECT NAME	BACNET OBJECT ID	BACNET DATA TYPE	LON SNVT NAME	SNVT TYPE	FUNCTION	DEFAULT	RANGE	DESCRIPTION
VFDActualFrequency	92	Analog Input	nvoVFDActFreq	SNVT_count	Monitor	-	0-65535	Frequency*10
VFDAmperage	93	Analog Input	nvoVFDAmps	SNVT_count	Monitor	-	0-1000	Amperage*10
VFDPower	94	Analog Input	nvoVFDPower	SNVT_count	Monitor	-	0-65500	kiloWatts*100

## IBT DDC Fault Codes

Code	Description
0	No Fault
1	Fire
2	Smoke
3	Gas PS High (Master)
4	Gas PS Low (Master)
5	IBT to IBT Comm Fail
6	Gas PS High (Slave)
7	Gas PS Low (Slave)
8	Exhaust Overload
9	Supply Overload
10	VFD571 IGBT Temp
11	VFD571 Output
12	VFD571 Ground
13	VFD571 Temp
14	VFD571 Flying Start
15	VFD571 High DC Bus
16	VFD571 Low DC Bus
17	VFD571 Overload
18	VFD571 OEM
19	VFD571 Illegal Setup
20	VFD571 Dynamic Brake
21	VFD751 Phase Lost
22	VFD751 External
23	VFD751 Control
24	VFD571 Start
25	VFD571 Incompat Param Set
26	VFD571 EPM HW
27	VFD571 Internal 1
28	VFD571 Internal 2
29	VFD571 Internal 3
30	VFD571 Internal 4
31	VFD571 Internal 5
32	VFD571 Internal 6
33	VFD571 Internal 7
34	VFD571 Internal 8
35	VFD571 Personality
36	VFD571 Internal 10
37	VFD571 Remote Keypad Lost
38	VFD571 Assertion Level
39	VFD571 Internal 11
40	VFD571 Internal 12
41	VFD571 Internal 13
42	VFD571 Internal 14
43	VFD571 Comm Module
44	VFD571 Network
45	VFD571 Network 1
46	VFD571 Network 2
47	VFD571 Network 3
48	VFD571 Network 4
49	VFD571 Network 5
50	VFD571 Network 6

Code	Description
51	VFD571 Network 7
52	VFD571 Network 8
53	VFD571 Network 9
54	Return Sensor Missing
55	Return Sensor Broken
56	Outside Sensor Missing
57	Outside Sensor Broken
58	Intake Sensor Missing
59	Intake Sensor Broken
60	Discharge Sensor Missing
61	Discharge Sensor Broken
62	HMI Temp Sensor
63	RTC 1 Temp Sensor
64	RTC 2 Temp Sensor
65	No Damper End
66	No Supply Air Proving
67	FSC1 High Temp
68	FSC2 High Temp
69	FSC3 High Temp
70	FSC4 High Temp
71	FSC1 Rollout
72	FSC2 Rollout
73	FSC3 Rollout
74	FSC4 Rollout
75	FSC1 Vent Proving
76	FSC2 Vent Proving
77	FSC3 Vent Proving
78	FSC4 Vent Proving
79	Freezestat Lockout
80	Firestat Lockout
81	Evap Water PS
82	Evap Float Detect
83	DX Float Detect
84	Modbus SysInfo Comm
85	Master ROM CRC
86	Slave ROM CRC
87	Clogged Filters
88	HMI 1 Version Wrong
89	HMI 2 Version Wrong
90	HMI 3 Version Wrong
91	HMI 4 Version Wrong
92	HMI 5 Version Wrong
93	Modbus Supply Vfd Comm
94	Modbus HMI Comm

## **Definitions**

**MVL** – Modulating Voltage Low – (.2V for 0-10V input, 2.1V for 2-10V input, .4mA for 0-20mA input, or 4.2mA for a 4-20mA input) - If the voltage stays below this set value for a certain amount of time the current relay will open.

**MVH** – Modulating Voltage High – (9.60V for either 0-10V or 2-10V, or 19.2mA for either 0-20mA or 4-20mA) - If the voltage stays above this set value for a certain amount of time the next relay will close.

**RCT** – Relay Close Time – The amount of time that the input voltage must stay above MVH before the next relay will close.

**ROT** – Relay Open Time – The amount of time that the input voltage must stay below MVL before the current relay will open.

**RTT** – Relay Tentative Time – The amount of time after a new relay has closed that the voltage must not drop or else the newly closed relay will open again.

**Number of Stages** - This will set the number of stages that are on the IBT.

**Resolution** – The resolution changes how often a sample is take and recorded from the input.

**Cycle Time** – The cycle time is the amount time that is stored in the history.

The number of samples that is stored in the history is calculated by (**Cycle Time/Resolution**).

## **Stage Operation**


During stage 1 the first burner is modulating the full range of the input, whether it be a 0-10V signal or a 2-10V signal. Once the input voltage has been above MVH for time RCT, a pre-purge cycle starts on the next burner.

If the input voltage still remains high and has not lowered for the entire 1 minute pre-purge, the second burner will then light and go into high-fire for 17 seconds. Stage 2 begins after the 17 seconds. During this stage the input is split into two sets of linearization data. Burner one will modulate from 0-10V from the first half of the input signal. Burner two will modulate from 0-10V from the second half.

For example, if the input is a 0-10V signal and has a value of 7V, burner one will be at max output of 10V and burner two will be around 4V (based on the current set of linearization data). If the input signal is a 2-10V signal and the value is 6V, burner one will be at 10V and burner two will be at 0V. This is because 6V is the very middle of the 2-10V scale for the input. If the input signal is a 0-10V signal and has a value of 1V, the first burner will have an output around 2V and the second burner will have an output of 0V.

This modulating scheme remains throughout the rest of the stages. If the input remains above MVH for time RCT after the preceding relay has closed, the third burner will begin its 1 minute pre-purge followed by 17 seconds of high fire and Stage 3 will be entered. After this 17 seconds the third burner will remain at high-fire while the first two burners continue to modulate. The fourth burner acts in the same manner as the third. If the input voltage ever remains below MVL for time ROT, then the last relay will be opened and that stage will shut off.

## Modulation Sequence



Stage	RCT				ROT (Seconds)	RTT (Seconds)
	Total # of stages					
	1	2	3	4		
First	0	0	0	0	45	60
Second	x	120	90	90	45	60
Third	x	x	120	90	45	60
Fourth	x	x	x	120	45	60



