



LEGEND

- AC AUTOMATIC CUTOFF
- MC MANUAL CUTOFF
- DS DISCONNECT SWITCH
- CONTACTOR COIL
- HEATING ELEMENT
- TR TRANSFORMER
- CONTACT NORMALLY OPEN
- FUSE

WARNING:
Disconnect all supplies before working on this duct heater

IMPORTANT:
Wire in according with electrical codes
Use copper wire for 90°C minimum

NOTE:
All wiring outside this frame are wiring by others

National Environmental Products Ltd 400, Lebeau, Montreal (QC) H4N 1R6
T: (514) 333-1433 F: 333-3163

ELECTRICAL DRAWING

PART NUMBER: RTUEC4-45KW6003
PROJECT NAME: RTUEC
CUSTOMER NAME: CAPTIVE AIRE, INC.

PROPRIETARY INFORMATION : THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION & IT'S PROPERTY OF N.E.P. LTD. THIS DOCUMENT AND THE INFORMATION IT CONTAINS SHALL NOT BE DUPLICATED OR USED IN WHOLE OR IN PART WITHOUT THE EXPRESS WRITTEN CONSENT OF N.E.P. LTD.