
## RTD SENSOR INSTALLATION

NOTES: One RTD per Exhaust Fan : RTD has 3 wires that connect to control cabinet

Revision History						
#	Description	Revised by	ECN#	Date		
0	Released to Website	JTS	1772	9/8/09		



Material: N/A	Part Number: N/A	Unless Otherwize Specified
Blank Size: N/A x N/A	MACOLA Number: N/A	Dimensions are in Inches.
Weight: N/A lbs	Drawing Name: Sensor_Install	Standard Tolerances are:
	Drawn By: JTS	Fractions: ±1/16 Decimal: .XX±.05
I ( _( )INEII )EINIIAI	Parent Assembly: RTD SENSOR	.XXX ±.015
	Sheet: 2 of 7	Angles: ±1°